

OPERATION MANUAL

BAM 1022 PLUS

Particulate Monitor
BAM 1022 PLUS-9800
Rev. B



Met One Instruments, Inc.
200 NE Greenfield Rd.
Grants Pass, OR 97526
Telephone: (541) 471-7111
Facsimile: (541) 471-7116
metone.com



POWERED BY ACOEM

Met One Instruments, Inc. is now part of the Acoem international group of companies.

Met One Instruments has been designing and manufacturing class-leading meteorological, ambient air sensing, and air quality monitoring instrumentation since its inception in 1989. Its line of robust industrial-grade meteorological equipment, air particulate monitoring equipment, and indoor air quality monitoring systems have set the standard for the industry. Headquartered in Grants Pass, OR, Met One Instruments, Inc. is fueled by a dedicated expert team who is diligently working to advance the technology required to ensure continued improvements in human and environmental health now and for generations to come.

Acoem is committed to helping organizations and public authorities find the right balance between progress and preservation – safeguarding businesses and assets and maximizing opportunities while conserving the planet’s resources. Headquartered in Limonest, France, Acoem delivers unrivaled inter-operable AI-powered sensors and ecosystems that empower our customers to make enlightened decisions based on accurate and timely information.

In 2021, Acoem acquired Met One Instruments, marking a pivotal moment when two industry leaders in the air quality monitoring sectors converged – creating a single, stronger and more future-focused provider of holistic environmental monitoring solutions. Now, Met One Instruments Powered by Acoem has opened new possibilities through an extensive offering of class leading, multi-parameter environmental monitoring and industrial reliability solutions. These integrated measurement systems, technologies, and services deliver comprehensive solutions for a range of applications, including environmental research, regulatory compliance, and industrial safety and hygiene.

For more information about Met One Instruments Powered by Acoem, please visit: metone.com

For more information about Acoem, please visit: acoem.com

BAM 1022 PLUS Operation Manual - © Copyright 2023 Met One Instruments, Inc. All Rights Reserved worldwide. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any other language in any form without the express written permission of Met One Instruments, Inc.

Table of Contents

1	INTRODUCTION	12
1.1	About This Manual	12
1.2	Technical Service	13
1.3	About the BAM 1022 PLUS Beta Attenuation Monitor	14
1.3.1	PTFE Filter Tape	15
1.4	Safety Statements	15
1.4.1	Beta Radiation	15
1.4.2	Other Safety Items.....	15
2	BAM 1022 PLUS SPECIFICATIONS	17
2.1	U.S. EPA Federal Equivalent Method.....	18
3	ACCESSORIES	19
4	INSTALLATION and COMMISSIONING	20
4.1	Unpacking.....	20
4.2	BAM 1022 PLUS Installation.....	21
4.3	BAM 1022 PLUS Power and Electrical Connections	27
4.4	Power-up and Automatic Operation	27
4.4.1	Power-up Settings Verification and Automatic Self-Test.....	27
4.5	Loading Filter Tape.....	29
4.6	Configuring External Sensors	31
4.6.1	Configuring the BX-597A Sensor	31
4.6.2	Changing Sensor Addresses	32
5	USER INTERFACE	33
5.1	Home Screen	34
5.2	Menu Hierarchy.....	35
5.3	User Interface Navigation	36
5.4	Operate Menu.....	37
5.4.1	Start Sample	37
5.4.2	Load Filter Tape	38
5.4.3	Transfer Data	38
5.4.4	About	38
5.4.5	Parameters Screens	39

5.5	Test Menu	39
5.5.1	Leak Test Screen	40
5.5.2	Ambient Temperature Screen.....	40
5.5.3	Ambient Pressure Screens.....	41
5.5.4	Flow Calibration Screens	41
5.5.5	Self-Test Screen.....	41
5.5.6	Filter Sensors Screens	42
5.5.7	Span Mass Audit Screens	42
5.5.8	Tape Test Screen.....	42
5.5.9	Nozzle and Count Test Screen	42
5.5.10	Analog Output Calibration.....	43
5.5.11	Inlet Heater Screen	44
5.5.12	Relay Test Screen	44
5.5.13	Digital Link Screen	44
5.6	Setup Menu	45
5.6.1	Set Clock Screen.....	45
5.6.2	Sample Screen	46
5.6.3	Flow Screen.....	46
5.6.4	Calibration Screen.....	46
5.6.5	Advanced	47
5.6.6	Tape Advance	47
5.6.7	Clear Memory Screen	48
5.6.8	Change Password Screen	48
5.6.9	Reports Screen.....	48
5.6.10	Station ID Screen	49
5.6.11	MET Average Screens.....	49
5.6.12	Analog Outputs Screen	49
5.6.13	Serial Port Screen	50
5.6.14	Modbus Screen.....	50
5.6.15	Ethernet Screen	51
5.6.16	Ethernet Config.....	51
5.6.17	Ethernet Timeout	51
5.6.18	Sound Volume	52
5.6.19	Touch Calibrate	52
5.7	Alarms Menu	52
6	OPERATION	53
6.1	Initial Startup Procedures	53
6.2	Warm-up Period	53
6.3	Commissioning	53
6.4	Sampling and Measurement Periods	54
6.4.1	Short Term Measurements	55
6.4.2	Standard Concentration	55

7	MAINTENANCE, ALARMS and TROUBLESHOOTING	56
7.1	Periodic Maintenance	56
7.2	Alarms	57
7.3	Hardware Failure Screen	58
7.4	Sensor Out of Range Event	59
7.5	Alarm Relay	59
7.6	Cleaning	59
7.6.1	Nozzle and Vane Cleaning	59
7.6.2	Internal Nozzle Cleaning	60
7.6.3	Clean Intake Fans and Filters	62
7.7	Leak Check	63
7.7.1	Filter Tape Leak Test	63
7.7.2	Total System Leak Test	64
7.7.3	Lower System Leak Test	65
7.8	Flow Audit and Calibration	66
7.9	Span Mass Audit	69
7.10	Background Determination (Mass Offset)	72
7.11	Filter Sensor Audit	74
7.11.1	Filter Temperature and Relative Humidity Sensors	74
7.11.2	Filter Pressure Sensors	75
7.12	Basic Problems & Solutions	77
8	DATA COLLECTION and COMMUNICATIONS	79
8.1	Analog & Digital I/O	80
8.2	Transfer Data to USB Flash Drive	81
8.3	Serial Communications	82
8.3.1	Terminal and Escape Commands Using the 7500 Protocol	82
8.4	Using Met One Comet Communications Software	86
8.5	Data Format & Example Reports	87
8.5.1	Settings Report	87
8.5.2	User Data Log Report	88
8.5.3	Alarm Log Report	89
9	THEORY of OPERATION	90
10	PARTS and ACCESSORIES	92
11	OPTIONAL BAM 1022 PLUS CONFIGURATIONS	95

11.1	Comet Cloud Service Data Modem.....	95
11.2	Wind Sensor Options	95
11.2.1	BX2-034	95
11.2.2	AIO 2	95
12	ACRONYMS and ABBREVIATIONS	97

Table of Figures

Figure 1-1 BAM 1022 PLUS.....	12
Figure 1-2 BAM 1022 PLUS Measurement System.....	14
Figure 4-1 Shipping Materials.....	20
Figure 4-2 Pump Box Assembly	21
Figure 4-3 Pump Connections Access Hole	22
Figure 4-4 Pump Connections.....	22
Figure 4-5 Pump Box Latch Secured	22
Figure 4-6 Electrical Connections Pannel.....	23
Figure 4-7 Pump Tubing Connection	23
Figure 4-8 Inlet Tube Receiver installed	23
Figure 4-9 Removing Inlet Shipping Caps	23
Figure 4-10 Inlet and Heater Installed.....	24
Figure 4-11 Heater Insulation Installed	24
Figure 4-12 Heater Power Connection	24
Figure 4-13 BX-597A Mounted	25
Figure 4-14 BX-597A Cable.....	25
Figure 4-15 BX-597A Sensor and Cable.....	25
Figure 4-16 BX-597A Terminal Block Connections	25
Figure 4-17 Ground Cable Installed.....	26
Figure 4-18 BX-802 and Cyclone Installed	26
Figure 4-19 Welcome Screen	28
Figure 4-20 Verifying the Clock.....	28
Figure 4-21 Verifying the Average Period.....	28
Figure 4-22 Verifying Filter Tape is Loaded	29
Figure 4-23 The Self-Test Screen	29
Figure 4-24 Plexiglas Removal	30
Figure 4-25 Filter Tape Path.....	30
Figure 4-26 The Digital Link Screen.....	31

Figure 4-27 Scanning for Sensors in the Digital Setup Screen	32
Figure 4-28 The Change Address Screen.....	32
Figure 5-1 BAM 1022 PLUS User Interface	33
Figure 5-2 Home Screens	34
Figure 5-3 Main Menu Access.....	36
Figure 5-4 Return to Home Screen.....	37
Figure 5-5 Parameters Screens	39
Figure 5-6 Test Menu Screens.....	39
Figure 5-7 Leak Test Screen	40
Figure 5-8 Ambient Temperature Screen.....	40
Figure 5-9 Ambient Pressure Screen	41
Figure 5-10 Flow Calibration Screens.....	41
Figure 5-11 Self Test Screen.....	41
Figure 5-12 Tape Test Screen.....	42
Figure 5-13 Nozzle/Count Test Screen	42
Figure 5-14 Analog Output Cal Screen	43
Figure 5-15 Analog Output Test Screen.....	43
Figure 5-16 Inlet Heater Screen.....	44
Figure 5-17 Relay Output Screen.....	44
Figure 5-18 Digital Link Screen.....	44
Figure 5-19 Set Up Menu Screens.....	45
Figure 5-20 Set Clock Screen	45
Figure 5-21 Sample Screen	46
Figure 5-22 Flow Screen	46
Figure 5-23 Calibration Screen.....	46
Figure 5-24 Advanced Screen Warning	47
Figure 5-25 Advanced Screen	47
Figure 5-26 Tape Advance Screen	47
Figure 5-27 Clear Memory Screens.....	48

Figure 5-28 Change Password Screen	48
Figure 5-29 Reports Screen	48
Figure 5-30 Station ID Screen	49
Figure 5-31 Met Average Main Screen	49
Figure 5-32 Met Average Options Screen	49
Figure 5-33 Serial Port Screen	50
Figure 5-34 Modbus Screen	50
Figure 5-35 Ethernet Screen	51
Figure 5-36 Ethernet Config Screen	51
Figure 5-37 Ethernet Timeout Screen.....	51
Figure 5-38 Sound Volume Screen.....	52
Figure 5-39 Touch Calibrate.....	52
Figure 5-40 Alarms Screen.....	52
Figure 7-1 Hardware Failure Screen.....	58
Figure 7-2 Nozzle Seal Cleaning.....	60
Figure 7-3 Vane Cleaning	60
Figure 7-4 Filter Tape Path	60
Figure 7-5 Nozzle Cleaning.....	61
Figure 7-6 Nozzle Seal Tool.....	63
Figure 7-7 BX-305 Leak Check Tool	65
Figure 7-8 Nozzle Seal Tool, Lower System Leak Test.....	66
Figure 7-9 Span Mass Audit Warning.....	69
Figure 7-10 Zero Span Foil Installation	69
Figure 7-11 Span Foil Installed.....	69
Figure 7-12 Span Mass Audit Sampling	70
Figure 7-13 Remove Zero Foil	70
Figure 7-14 Span Mass Audit Value	70
Figure 7-15 Insert Span Foil	71
Figure 7-16 Span Foil Installed Above Tape	71

Figure 7-17 Span Mass Audit Results.....	71
Figure 7-18 Span Foil Test Complete	72
Figure 7-19 Filter Sensor Main Audit Screen	74
Figure 8-1 Terminal Block Connections.....	80
Figure 8-2 Copy Data to USB Main Screen.....	81
Figure 8-3 Data Copy to USB Complete.....	81
Figure 8-4 Comet Program Interface	86

Table of Tables

Table 2-1 Specifications Table.....	17
Table 4-1 BX-587A Wiring.....	25
Table 4-2 Power Consumption	27
Table 5-1 Menu Hierarchy	35
Table 7-1 Periodic Maintenance	56
Table 7-2 Alarm Code Descriptions.....	58
Table 7-3 Sensor Ranges.....	59
Table 7-4 Calibration Equipment Acceptance Criteria	67
Table 7-5 Flow Control System Acceptance Criteria	67
Table 8-1 Serial to Terminal Block Wiring	82
Table 8-2 Escape Commands	83
Table 8-3 Command Ranges.....	84
Table 8-4 User Data Storage Capacity	88
Table 10-1 Parts and Accessories	92

1 INTRODUCTION

1.1 *About This Manual*

This document is organized with the most important information towards the front of the manual, such as site selection, installation, setup, and field calibrations, which all BAM 1022 PLUS owners and operators must read and understand. Towards the back are sections that provide in-depth information on subjects such as theory, diagnostics, accessories, and alternate configurations. These sections provide valuable information that should be consulted as needed. Electronic versions of this manual are also available. Operators of the monitoring system are encouraged to study this manual to ensure correct performance, safe operation, and to prevent equipment damage.




Figure 1-1 BAM 1022 PLUS

1.2 Technical Service

This manual is structured by customer feedback to provide the required information for setup, operation, testing, maintaining, and troubleshooting the BAM 1022 PLUS. Should you still require support after consulting the documentation, we encourage you to contact one of our expert Technical Service representatives during normal business hours of 7:00 a.m. to 4:00 p.m. Pacific Time, Monday through Friday. Product warranty information is available at <https://metone.com/met-one-warranty>. In addition, technical information and service bulletins are often posted on our website. Please contact us and obtain a Return Authorization (RA) number before sending any equipment back to the factory. This allows us to track and schedule service work and to expedite customer service.

Contact	Tel: + 541 471 7111	Address: Met One Instruments
Information:	Fax: + 541 471 7116	200 NE Greenfield Rd.
	Web: www.metone.com	Grants Pass, Oregon
	Email: service.moi@acoem.com	97526 U.S.A.

Please have the instrument serial number available when contacting the manufacturer. On most models manufactured by Met One Instruments, it will be located on a silver product label on the unit and also printed on the calibration certificate. The serial number will begin with a letter(s) and be followed by a unique five-digit number such as U15915.

1.3 About the BAM 1022 PLUS Beta Attenuation Monitor

The Met One Instruments Model BAM 1022 PLUS high-performance beta gauge utilizes the principle of beta ray attenuation to accurately measure and report the concentration of ambient particulate matter. Beta gauges have the advantage of being sensitive only to the mass and not to the physical, chemical, or optical properties of the sampled aerosol.

A vacuum pump draws air through a size selective inlet, down the inlet tube, and deposits the airborne particulate on PTFE filter tape that is located between the beta source and detector. The accumulation of mass onto the filter tape increasingly attenuates beta ray transmission through the media.

Beta attenuation through the filter tape is continuously monitored throughout the measurement cycle. The degree of beta ray attenuation is used to determine the mass of particulate matter deposited on the filter tape. During sampling, the flow rate is precisely controlled.

Having determined both mass and sample volume, the BAM 1022 PLUS calculates and reports the ambient PM concentration, expressed as $\mu\text{g}/\text{m}^3$ or mg/m^3 .

A detailed description of the measurement is provided in **Section 9** of this Operating Manual.




Figure 1-2 BAM 1022 PLUS Measurement System

NOTE: For proper performance, the BAM 1022 PLUS must be operated outdoors and should not be installed inside of a building, trailer, or other shelter. It must be allowed to run under ambient conditions. This is required for the BAM 1022 PLUS to operate as a U.S. EPA PM_{2.5} Class III Equivalent Method.

1.3.1 PTFE Filter Tape

The BAM 1022 PLUS uses filter media, or filter tape, consisting of extremely thin PTFE bonded to a fibrous polyester backing. The tape comes in 50-m long rolls, has been given the part number 460185, and is available only through Met One Instruments, its subsidiaries, or distributors. To operate the BAM 1022 PLUS as an EPA-designated equivalent method for PM_{2.5}, this PTFE filter tape (P/N 460185) must be used. Because of mechanical changes that have been made to accommodate the PTFE tape, the glass fiber tape used in the BAM-1022 is incompatible with the BAM 1022 PLUS and must not be used.

1.4 Safety Statements

1.4.1 Beta Radiation

The Met One Instruments BAM 1022 PLUS contains a small ¹⁴C (Carbon-14) beta radiation-emitting source. The specified activity of the source is 100 μCi +0/-20μCi (microcuries), which is below the “Exempt Concentration Limit” as defined in USC 10 CFR Section 30.71 – Schedule B. The owner of the BAM 1022 PLUS is not required to obtain any license in the United States to own or operate the mass monitor. The owner of a BAM 1022 PLUS may elect to return the entire mass monitor to Met One Instruments for recycling of the ¹⁴C source when the mass monitor has reached the end of its service life, although the owner is under no obligation to do so. Under no circumstances should anyone but factory technicians attempt to remove or access the beta source. The beta source has a half-life of about 5,730 years and should never need to be replaced unless it becomes damaged. Neither the ¹⁴C source nor the beta ray detector are serviceable in the field. Should these components require repair or replacement, the BAM 1022 PLUS must be returned to the factory for service and recalibration. The BAM 1022 PLUS is manufactured in compliance with the U.S. NRC safety criteria in 10 CFR 32.27.

1.4.2 Other Safety Items

If the BAM 1022 PLUS is operated in a manner not specified by the manufacturer, the performance and protection provided by the equipment may be impaired.

- Any repairs or adjustments made to the BAM 1022 PLUS that are not outlined within this document must be carried out only by factory-trained personnel. Under no circumstances should repairs be attempted by personnel not qualified to service electronic instrumentation.
- Disconnect power to the BAM 1022 PLUS power before working on electrical components. Failure to do so may result in an electrical hazard and could damage the equipment.
- Grounding and antistatic procedures must be followed when handling any internal components. Internal circuitry of the BAM 1022 PLUS may be damaged by static electricity.
- Do not operate the BAM 1022 PLUS in potentially explosive environments.

- If safe operation of the BAM 1022 PLUS has been impaired, the instrument must be disconnected from power and secured against unintended operation.
- The BAM 1022 PLUS should be secured against accidental tipping. Anchoring holes are provided in the feet at the base of pump box assembly for this purpose.

For procedures not outlined within this document, consult your local Met One Instruments technical service representative or contact the manufacturer.

2 BAM 1022 PLUS SPECIFICATIONS

Table 2-1 Specifications Table

PARAMETER	SPECIFICATION
Measurement Principle	Beta Attenuation.
US EPA Designations	EPA Class III Federal Equivalent Method (EQPM-1013-209)
Measurement Range	0 $\mu\text{g}/\text{m}^3$ – 10,000 $\mu\text{g}/\text{m}^3$
Accuracy	Meets US-EPA Requirements for Class III PM _{2.5} FEM
Measurement Resolution	0.1 $\mu\text{g}/\text{m}^3$
Lower Detection Limit	< 2.4 $\mu\text{g}/\text{m}^3$ (Hourly, 2 σ) / < 0.5 $\mu\text{g}/\text{m}^3$ (24 Hour, 2 σ)
Sampling Time	Continuous Air Sampling with Hourly Tape Advance
Measurement Cycles	Primary: Automatic Hourly PM Measurement (Required for PM _{2.5} FEM Operation) Secondary (Conc RT): User Selectable Short-Term Averages (5 to 60 minutes)
Sample Flow Rate	16.7 liters/minute
Flow Accuracy	\pm 2.0 %
Filter Tape	PTFE with polyester backing, 30 mm x 50 m roll. Up to 4 months operation per roll with hourly tape advance.
Maintenance Interval	8 Weeks (minimum)
Span Check	Manual Audits Performed with Zero and Span Foils (Included)
Beta Source	¹⁴ C (carbon-14), 100 μCi +0/-20 μCi (< 3.7 MBq) Half-Life 5730 years.
Detector Type:	Photomultiplier tube with scintillator
Operating Temperature Range	-30° to +50° C
Operating Humidity Range	0 to 90% RH, non-condensing
User Interface	4.3" graphical touch screen
Analog Output	Two channels; optically isolated; 0-1, 0-2.5, 0-5 VDC
Alarm Contact Closure	1 channel; dry NO contact; 1 A at 125 VAC or 60 VDC maximum.
Serial Interfaces	1 channel; full duplex RS-232, USB serial (Shared common serial output). Baud rates 2400, 4800, 9600, 19200, 38400, 57600, 115200. 1 channel; half duplex RS-485. Baud rates 2400, 4800, 9600, 19200, 38400, 57600, 115200. 1 channel; Ethernet
Compatible Software	Comet™, Air Plus™, terminal programs.
Data Logger Memory	22,528 records (2.6 years @ 1 record/hr. 15.6 days @ 1 record/min).
Unit Dimensions	55.9 cm wide x 45.7 cm deep x 139.7cm high (22"w x 18"d x 55"h)
Weight	38.6 kg (85 lbs) fully assembled
Power Supply	100-240 VAC 50/60 Hz universal input; 12 VDC, 8.5 A output
Power Consumption	115 VAC Setup: Approx. 300 W (incl. BAM 1022 PLUS, Inlet Heater, Pump, & Fans). 230 VAC Setup: Approx. 850 W (incl. BAM 1022 PLUS, Inlet Heater, Pump, & Fans).
Approvals	NRC, ISO 9001, ROHS, US-EPA

Specifications may be subject to change without notice.

2.1 U.S. EPA Federal Equivalent Method

The BAM 1022 PLUS Beta Attenuation Mass Monitor is US-EPA designated for PM_{2.5} under the following designation number:

Designation Number: EQPM-1013-209 (PM_{2.5} with BGI/Mesa Labs VSCC™ or Tisch Cyclone)

US-EPA designated methods may be modified by the manufacturer from time to time to reflect hardware improvements, software improvements, or operational changes. Met One Instruments, Inc., in conformance with 40CFR 53.14, modified the BAM-1022, which is EPA-designated as a Class 3 PM_{2.5} FEM, resulting in the higher sensitivity and performance BAM 1022 PLUS. The BAM 1022 PLUS retains the US-EPA designation of the BAM-1022, but it must be operated in conformance with the contents of the BAM 1022 PLUS operational manual.

3 ACCESSORIES

Every BAM 1022 PLUS requires the use of ancillary components. The items supplied with the standard BAM 1022 PLUS PM_{2.5}FEM monitoring system are as follows:

Standard Components	Part No.
Zero Filter Kit	BX-302
PM ₁₀ Size Selective Inlet	BX-802
PM _{2.5} Very Sharp Cut Cyclone	BX-808
Inlet Tube Heater	80559
Inlet Tube Heater Insulation Sleeve	9123-2
Inlet Tube (27 inches)	8112-2.25
Ambient Combination Sensor (AT, BP, RH)	BX-597A
Filter Tape	460185
Accessory Kit*	83035

*See **Section 10** for a complete listing of all items contained in the Accessory Kit

Application and installation dependent accessories for the BAM 1022 PLUS are available from Met One Instruments.

Common Optional Component	Part No.
Volumetric Flow Calibrator	Swift 25.0

4 INSTALLATION and COMMISSIONING

4.1 Unpacking



Figure 4-1 Shipping Materials

Any damages incurred to the equipment during shipping are the responsibility of the carrier. If any damage to the shipment is noticed before unpacking, **a claim should be filed with the commercial carrier immediately**. You should follow any special unpacking instructions provided by the carrier and then carefully remove all items from the containers and inspect each component. It is recommended that you document and photograph all damaged packages and items before, during, and after unpacking them. Contact Met One Instruments (see **Section 1.2** of this manual) to arrange for any replacement items needed.

Unpack the mass monitor and accessories and compare them to the packing list to make sure all items are present.

The BAM 1022 PLUS is shipped with a white plastic shim pinched under the nozzle of the mass monitor which prevents the moving parts of the nozzle assembly from being damaged in transit.

Important: Remove the nozzle shim prior to instrument operation.

The shim should be replaced in its original location anytime the mass monitor is being transported to avoid damaging the nozzle control mechanism. Do not ship or transport the BAM 1022 PLUS with filter tape installed.

Please keep all the special shipping items (box, foam packing material, etc.) used to ship your BAM 1022 PLUS. They should be re-used if you must transport your monitor (changing site locations, returning to the factory, etc.). Met One is not responsible for damage to the mass monitor if shipped in non-original packaging, or without the shim in place. Contact Met One Instruments (see **Section 1.2** of this manual) for replacement packing materials if necessary.

4.2 BAM 1022 PLUS Installation

The BAM 1022 PLUS is a weatherproof monitor and must be operated outside of any additional enclosures to maintain its US-EPA Class III designation. Its housing is designed to maintain a near constant temperature difference between ambient and measurement conditions. The required constant temperature difference will not be achieved if the BAM 1022 PLUS is installed inside of any structure where the temperature is not allowed to vary with ambient temperature.

There are no special precautions or handling concerns except for the normal level of care required for handling scientific equipment.

1. Remove the cover from the top of the pump box assembly and set it aside. Remove all packing material from inside the box and gather the loose ends of the cables and tubing.
2. Invert the cover so that the white nipple is protruding upward, feed the cables and tubing through it from the bottom, and then replace it atop the pump box assembly. It should look like the picture shown here. Ensure the fan power cable does not become disconnected from the fan.




Figure 4-2 Pump Box Assembly

3. Open the front door of the main enclosure and remove the protective packing material from around the touch screen display. On the back of the enclosure, undo the four wing nuts holding the cable access cover in place and then remove the cover. Set it aside for now.
4. Behind the cable access panel, locate the hole on the right-hand side of the bottom of the enclosure. Lift the monitor and carefully feed the cabling through this hole and continue to lower it until the pump box nipple extends into the housing and the monitor is resting flat on top of the pump box assembly. Raise the side latches and secure them in place by tightening the large knob. See pictures below.



Figure 4-3 Pump Connections Access Hole



Figure 4-4 Pump Connections




Figure 4-5 Pump Box Latch Secured

CAUTION: Lift the BAM 1022 PLUS only using the side handles. If needed, use team lifting.

5. Route the pump cable, the pump box fan cable, and the pump tubing to the appropriate locations and plug them in to the monitor. Be sure to connect the ground lead tied to the yellow pump cable to the grounding connection on the BAM 1022 PLUS power distribution box. Note that the pump cable connection is a twist lock type. Once inserted, rotate it slightly in a clockwise direction to lock it in place. To insert the tubing, simply press it into the fitting. See photos below.



Figure 4-6 Electrical Connections Panel




Figure 4-7 Pump Tubing Connection

6. Wrap the lower threads of the pipe seal with Teflon tape and install it in the top of the enclosure. See picture to the right.



Figure 4-8 Inlet Tube Receiver installed

7. Locate the red cap covering the inlet tube receiver inside the BAM 1022 PLUS enclosure. It is found just to the left of the touchscreen display. Remove the large red cap and a smaller red insert will be revealed beneath it. Remove this insert as well.



Figure 4-9 Removing Inlet Shipping Caps

- Slide the inlet tube through the pipe seal on top of the enclosure just until you can see it inside the enclosure. Position the inlet heater beneath the inlet tube and slide the tube through the heating element until it just meets the O-rings. Raise the heater so it is near (but not touching) the top of the enclosure and fasten it in position with the supplied hex wrench.



Figure 4-10 Inlet and Heater Installed

- Rotate the tube so that the heater power cable is facing the back left corner of the enclosure and route the cable down the large empty hole located near the left corner. Push the inlet tube down all the way and wrap the heater element in the supplied insulating material as shown in the above right image.




Figure 4-11 Heater Insulation Installed

- Route the inlet tube heater to the power connection labeled HEATER in the back of the BAM 1022 PLUS and plug it in. Note that this connection is a twist lock type. Once inserted, rotate it slightly in a clockwise direction to lock it in place.



Figure 4-12 Heater Power Connection

11. Install the BX-597A probe on the inlet tube above the roof of the BAM 1022 PLUS enclosure using the U-bolt with the nuts and washers provided. Connect the silver connector of the cable to the silver connection on the bottom of the sensor. See pictures below.



Figure 4-13 BX-597A Mounted



Figure 4-14 BX-597A Cable



Figure 4-15 BX-597A Sensor and Cable

12. Route the sensor cable to the back of the enclosure and attach it to the SENSOR NETWORK terminals in the top position.




Figure 4-16 BX-597A Terminal Block Connections

Table 4-1 BX-587A Wiring

BX-597A WIRE COLOR	BAM 1022 PLUS TERMINAL NAME
RED	DC PWR
ORANGE or YELLOW	RS485+
WHITE	RS485-
BLACK	GND
WHITE W/BRWN	SHIELD

13. Install the AC power supply cable to the remaining connection on the bottom of the internal power strip. It is located next to the ON/OFF switch. See photo above right. Route the power cable and the sensor cable out of the bottom of the cable access opening.
14. Connect the 9528 grounding cable (included in the accessory kit) to the ground connection shown in photo above. Route the ground cable out of the bottom of the cable access opening and connect it to the isolated site grounding rod.



Figure 4-17 Ground Cable Installed

15. Remove the inlet protector plugs from the BX-802 PM₁₀ inlet head and BX-808 PM_{2.5} Very Sharp Cut Cyclone. Install the BX-808 on top of the inlet tube and then the BX-802 directly above it.



Figure 4-18 BX-802 and Cyclone Installed

16. Plug the AC power cable into your AC source and turn the power switch to ON. Verify the fans start up in both the pump box and the main enclosure. The touchscreen display should also turn on as described in **Section 4.4.1**.

17. Replace the cable access cover panel on the back of the enclosure and affix it in place with the four wing nut fasteners. Be sure the flange is on the bottom so that the power cable and the sensor cable will be pinned between the foam strips and held in place.

4.3 **BAM 1022 PLUS Power and Electrical Connections**

The BAM 1022 PLUS should be powered by either a 110 VAC 50/60Hz or 220 VAC 50/60 Hz source. Before proceeding with electrical connections, review the following notifications:

- Ensure that the monitoring site main power (voltage and frequency) is compatible with the version of BAM 1022 PLUS monitor and accessories that has been purchased. Consult the electrical labels on the devices.
- All electrical connections must be in accordance with national codes. Always use grounded receptacles and power cords.

A dedicated 15 Amp electrical circuit is adequate to run a single BAM 1022 PLUS system. A summary of instrument power consumption is provided below:

Table 4-2 Power Consumption

Description	Amps	Watts
BAM 1022 PLUS on, pump and inlet heater off (115 VAC).	0.4 A	46 W
BAM 1022 PLUS, pump and inlet heater on (115 VAC).	2.6 A	299 W
BAM 1022 PLUS on, pump and inlet heater off (230 VAC).	0.3 A	69 W
BAM 1022 PLUS, pump and inlet heater on (230 VAC).	3.7 A	851 W

4.4 **Power-up and Automatic Operation**

The BAM 1022 PLUS is designed to run automatically when the power switch, inside the rear panel is toggled UP in the ON position. The unit will ask if you are ready to start, then prompt you to verify several setup menus which are described below.

Note: If no user activity is detected for several minutes after power-up, the BAM 1022 PLUS will automatically begin sampling based on the existing SETUP options and settings, if filter tape is installed, and no hardware or voltage failures are detected. This makes it possible to fully configure and calibrate the unit in the lab, then simply deploy it to the field and power it up with no further actions required.

4.4.1 **Power-up Settings Verification and Automatic Self-Test**

The BAM 1022 PLUS will prompt you to verify several setup parameters whenever it is powered on. These setup screens can also be viewed or edited in the SETUP menu under the main BAM 1022 PLUS menu system. See **Section 5.6** for detailed descriptions of the SETUP parameters.

When power is applied to the BAM 1022 PLUS, the unit will show the startup splash screen for the touchscreen display for a moment, then display the welcome screen:




Figure 4-19 Welcome Screen

Press the SETUP button and the clock screen is displayed as shown below left. If the time and date are correct, press the YES button again. If you need to change the date or time, press the EDIT button. See **Section 5.6.1** for details on changing the date and time.




Figure 4-20 Verifying the Clock

After the time is verified, the unit will display the Settings screen shown below. If the settings need to be changed, press the green bordered value box to be updated and the associated edit screen will be displayed.

This menu is important to understand. See **Sections 5.6.10** and **5.6.11** for detailed descriptions of these parameters. Press OK if the settings are correct.




Figure 4-21 Verifying the Average Period

After verifying the settings, the BAM 1022 PLUS will need to check if a roll of filter tape is installed. First, you will be instructed to remove the shipping vane protector if it is installed. Then the monitor will check the tape installation. If no tape is detected, the unit will prompt you to install a new roll:




Figure 4-22 Verifying Filter Tape is Loaded

Install a roll of filter tape as described in **Section 4.5**. When the filter tape is installed, press MOVE. The unit will again try to detect the tape.

If tape is detected, the unit will proceed to the Self-Test screen as shown in the images below. Press START to begin the self-test. After the self-test is complete, press X to exit and start operation.




Figure 4-23 The Self-Test Screen

4.5 Loading Filter Tape

Filter tape must be installed before sampling commences.

Use the following steps to load the roll of filter tape:

1. Press the “Operate Menu” button and select the “LOAD FILTER TAPE” option. Entering this screen will cause the nozzle to raise and instructions to load the tape per the door mounted diagram are displayed.
2. Remove the Plexiglas cover by pulling out at the bottom to release the Velcro holding strip, and then lifting the cover off the two alignment pins at the top (see below).

Important: Remove the nozzle shim prior to instrument operation. See Section 4.1





Figure 4-24 Plexiglas Removal

3. Unscrew and remove the two clear plastic reel covers and both tape spool cores.
4. Make sure the nozzle and vane are completely clean of debris. Cleaning procedures are detailed in **Section 7** of this manual.
5. Slide an empty tape spool core on to the take-up reel (on the left). You may use the empty spool core that was just removed from the supply reel (on the right) or the gray core tube (part number 8150) supplied with the instrument
6. Unwrap a new roll of filter tape. Place the full roll on the supply reel and route the tape through the nozzle and vane as indicated on the inside of the door of the instrument. When loading the filter tape, the fibrous side should always be facing down and the PTFE side should always be facing up.




Figure 4-25 Filter Tape Path

7. Fasten the loose end of the new filter tape to the take-up spool core with a piece of tape.
8. Rotate the spools by hand to remove tape slack.
9. Replace the two clear plastic reel covers and fasten the screws tightly by hand.

10. Press the gray MOVE button to move the tape and verify it has been properly loaded.
 - i. If the tape is correctly installed, the display will report “TAPE IS OK!” in green letters beside the gray button.
 - ii. If there is a problem, it will report “TAPE FAIL” in red letters.
 1. Verify the tape is properly routed.
 2. Remove any slack by rolling up loose tape on the tape spools.
 3. Press the MOVE button again to take out any additional slack and verify the tape is loaded correctly.

Notes:

- One roll of filter tape will last approximately 4 months when the BAM 1022 PLUS is set up to operate as a U.S. EPA PM_{2.5} federal equivalent method “FEM”.
- Filter tape should never be re-used. This will lead to measurement errors.
- For continuous monitoring requirements, it is recommended that spare filter tape rolls be kept in stock by the owner / operator. See **Section 10** for ordering information.

4.6 Configuring External Sensors

The BAM 1022 PLUS must have a BX-597A sensor connected and properly configured for operation. If the BX-597A is not present, the BAM 1022 PLUS will not begin sampling. See **Section 11.2** for more details about available wind sensors.

4.6.1 Configuring the BX-597A Sensor

The BAM 1022 PLUS requires a BX-597A sensor at address 1 of its serial network to begin sampling. Once the physical connections are made (see **Section 4.2**), the sensor is programmed using the Digital Link screen located in the Test menu (see **Section 5.5.13**).

Upon entering the Digital Link screen, any digital sensor connected to the BAM 1022 PLUS with address 1 or 2 programmed in it will appear in either the Sensor 1 or Sensor 2 fields, as appropriate. In addition to the sensor type, the address fields on this screen also display the firmware currently installed in the sensor. This image (right) shows a dual sensor configuration.

Digital Link	
Digital Link	OK
Sensor 1	597A R1.0.1
Sensor 2	MSO R1.1.0
State	RQ Wait
SETUP	

Figure 4-26 The Digital Link Screen

The State field indicates that the BAM 1022 PLUS is either starting up digital communications or waiting for a response from the sensor. If either the sensor type or firmware revision is missing or incorrect, communications are not properly established with the sensor. The gray SETUP button in the lower left corner provides access to the Digital Setup screen for configuring the addresses of the digital sensors. See **Section 4.6.2** for details.

4.6.2 Changing Sensor Addresses

By default, most digital sensors provided by Met One Instruments, Inc. are set to address 1.

If a connected sensor has an address other than 1 or 2, it can be detected and changed in the Digital Setup screen by pressing the gray SCAN button in the bottom left corner (see image right). The BAM 1022 PLUS will scan through all potential network address nodes in an attempt to locate any connected devices. Progress of this scan can be seen in the third address field label (which displays Addr 3, by default) and the word “Scanning” will appear in the field itself.



Figure 4-27 Scanning for Sensors in the Digital Setup Screen

If a device is located at some other address, it can be changed by pressing the gray CHANGE button next to its address field. In the example shown to the right, the BX-597A has been configured for address 43. Pressing the gray SET 1 button will update the address in the sensor to address number 1 and exit back to the main Digital Link screen. The Sensor 1 field will now display the BX-597A details like the image in **Figure 4-26**.



Figure 4-28 The Change Address Screen

If two sensors share the same address, disconnect one of them and then use the CHANGE button to set the connected sensor to a different address. Remember that the BX-597A must be configured for address number 1 and if an optional wind sensor is connected, it will need to be set to number 2.

5 USER INTERFACE

The BAM 1022 PLUS user interface is a touchscreen display used to control almost all of the features and functionality of the monitor. It is mounted on a hinged bracket located inside the enclosure near the inlet tube in the upper right-hand corner of the monitor. The center screw of the mounting bracket hinge adjusts the amount of force necessary to reposition the bracket.



Figure 5-1 BAM 1022 PLUS User Interface

5.1 Home Screen

In addition to the 1-hour concentration (Conc HR) reading reported under actual conditions, this screen shows the standard concentration (Conc S), current real time values being measured (Conc RT), and the operational state of the BAM 1022 PLUS. This image below on the left-hand side is the screen that will normally be displayed.

BAM 1022 PLUS		2026-01-07 15:44:35
Conc HR	6.8	ug/m3
Status	SAMPLING	
ConcS	6.6 ug/m3	
Conc RT	2.6 ug/m3	
Flow	16.68 LPM	
▼		

BAM 1022 PLUS		2026-01-07 15:45:14
Conc HR	6.8	ug/m3
AT	4.7 C	
RH	92 %	
BP	727.9 mmHg	
▼		

BAM 1022 PLUS		2026-01-07 15:45:46
Conc HR	6.8	ug/m3
FT	25.1 C	
FRH	26 %	
WS	0.0 m/s	
WD	0 Deg	
▼		

Figure 5-2 Home Screens

Note that the display has a limited amount of space and cannot show all real time data on one screen. Press the arrow key in the lower left corner of the display to navigate through the three screens shown above.

NOTE: A concentration value of 99.999 mg/m³ or 99999 µg/m³ is an invalid concentration measurement and is due to an appropriate alarm condition.

The table below describes the parameters visible in the Home. In addition to the hourly, standard, and real-time average concentrations, the logged parameters in the BAM 1022 PLUS are:

Parameter	Description
Conc HR	The concentration at Actual conditions of the last hourly sample
Status	The current operational status or alarm condition of the monitor
ConcS	The concentration (at Standard conditions) of the last hourly sample
Conc RT	The average real-time period concentration
FLOW	Primary air flow rate in actual LPM
AT	BX-597A Ambient Temperature
RH	BX-597A ambient Relative Humidity
BP	BX-597A ambient Barometric Pressure
FT	Internal Filter Temperature after the filter tape in degrees C
FRH	Internal Filter RH after the filter tape
WS	Wind speed in meters per second (if equipped)
WD	Wind direction in degrees (if equipped)

5.2 Menu Hierarchy

The BAM 1022 PLUS menu structure is outlined in the following table.

Table 5-1 Menu Hierarchy

Main Menu	Sub Menu Options	Overview
Operate See Section 5.4	Start Sample Load Filter Tape Transfer Data About Parameters Conc Chart	Begin or resume monitoring (will indicate Stop Sample, if sampling) Load and properly tension the filter tape Download stored data to a USB memory stick Details the unit serial number and firmware revision number Displays current real time values for operating parameters Displays the hourly concentration for the last 24-hours in chart form
Test See Section 5.5	Leak Test Ambient Temperature Ambient Pressure Flow Calibration Self-Test Filter Sensors Span Mass Audit Tape Test Inlet Heater Nozzle/Count Test Digital Link Relay Output Analog Calibration Analog Output	Perform the leak test Calibrate ambient temperature or restore default settings Calibrate ambient pressure or restore default settings Calibrate flow rate or restore default settings Run the BAM 1022 PLUS Self-Test Calibrate filter temp, filter RH, and pressure or restore defaults Run the zero and span foil tests Verify tape travels expected distance Manually turn the inlet heater on and off Test nozzle operation and verify beta counting Test digital communications with the BX-597A sensor Manually open and close the alarm relay Calibrate the analog output Test the analog output

Table 5.1 Menu Hierarchy (Continued)

Main Menu	Sub Menu Options	Overview
Setup See Section 5.6	Clock Sample Flow Calibration Tape Advance Clear memory Password Reports Station ID MET Average Analog Outputs Serial Port Modbus Ethernet Ethernet Config Sound Volume* Touch Calibrate* Language	Set the date and time Set the averaging interval for real time data; set concentration units Set the temperature used for calculating Standard Flow Volume Change the concentration offset and span membrane values. Set the differential pressure threshold for advancing the filter tape Clear all stored data Change the master password Set the type of time stamp to use for the hourly report Set the ID (or location) number used to identify the BAM 1022 PLUS Set the averaging interval for collecting other than hourly data Set the parameters for both analog outputs Set the baud rate and connection type for serial communications Set the active slave Modbus port and address Set the IP address, subnet mask, and gateway values View the current Ethernet settings Adjust the volume of the touchscreen sounds Calibrate the touch screen Select the preferred language
Alarms See Section 5.7	No sub menu	View alarms

* These items will not be available with the 82564 display option. To identify the display type, see section 5.4.4

5.3 User Interface Navigation

To access the various main menus, press the three horizontal lines in the top left corner. A drop-down menu will appear (see right) to allow selection of any of the four main menus. This option is available on all main menu screens (such as the Setup Menu shown below) and on the Home screen.




Figure 5-3 Main Menu Access





Figure 5-4 Return to Home Screen


To return to the Home screen (see **Section 5.1**), press the Home icon located in the upper right corner of all main menu screens. This icon can clearly be seen in the Setup Menu image shown here on the left.

To cancel an action and return to the previous menu screen, press the X icon located in the upper right corner of all sub menu screens. This icon can clearly be seen in the Set Clock Menu image to the right.




5.4 Operate Menu

The Operate Menu is the doorway to the most used areas for normal operation of the BAM 1022 PLUS.




5.4.1 Start Sample

This screen allows users to both start and stop the BAM 1022 PLUS sampling process. Upon entering this screen, a warning will be displayed asking users if they would like to start or stop a sample, depending on the current state of the monitor. If there is no sample currently being taken, the gray button in the lower left corner will be labeled START. If there is a sample in progress, it will read STOP.



5.4.2 Load Filter Tape

This screen provides the options needed to load and tension the filter tape. See **Section 4.5** for detailed instructions on loading filter tape.



5.4.3 Transfer Data

Copying data to a USB memory stick is performed from this screen. See **Section 8.2** for detailed instructions. For compatibility, USB flash drives must be formatted with the FAT or FAT32 file system.

5.4.4 About

This screen shows the monitor's model number, serial number, and installed firmware types and version numbers. . An alternate display is supported and can be identified by the part number. 82451 is the original display and 82564 is the alternate display.

About	
Website	www.metone.com
Serial Number	C19687
Firmware Version	82912-1, R2.6.10
Display Version	82451, R1.2

5.4.5 Parameters Screens

These screens are not password protected. They provide the ability to view the real time value of a wide variety of parameters. Results are updated once per second. No changes can be made in this screen. It is for viewing purposes only.




Figure 5-5 Parameters Screens

Note that the display has a limited amount of space and cannot show all the real time data on one screen. Tap the down arrow key in the lower left corner of the display to scroll through the screens shown above. Tapping the arrow on the last screen will return you to the first one.

5.5 Test Menu

The Test Menu provides a means of testing and calibrating individual sensor inputs and calculations. Because these settings directly impact flow and concentration values, most of these tests are password protected.




Figure 5-6 Test Menu Screens

5.5.1 Leak Test Screen

This screen provides the options and indications needed to perform a leak test of the sampling system. The gray pump control button in the lower left corner will read PUMP ON which indicates that pressing it will turn on the pump. Similarly, when the pump is running, this button will display PUMP OFF.




Figure 5-7 Leak Test Screen

Use the LEAK ON button to lock the flow controller at its current value. This forces the flow controller not to change regardless of blocking the flow or not.

The gray nozzle control button in the lower right corner will always be labeled as NOZZLE when you first enter this test screen. Pressing it will cause the nozzle to change state from up to down or down to up. The button will now display what will happen if you press it again, just like the pump control button. This means that it will read NOZZLE UP if the nozzle is in the down position or NOZZLE DOWN if it is in the up position.

The flow and lower pressure sensor indications are provided for reference when performing the leak test. See Section 7.7 for detailed instructions on performing a leak test.

5.5.2 Ambient Temperature Screen

This screen provides the options and indications needed to default, verify, and calibrate the ambient temperature sensor as part of the flow audit and calibration. See Section 7.8 for detailed instructions.




Figure 5-8 Ambient Temperature Screen

5.5.3 Ambient Pressure Screens

This screen provides the options and indications needed to default, verify, and calibrate the ambient pressure sensor as part of the flow audit and calibration. See **Section 7.8** for detailed instructions.




Figure 5-9 Ambient Pressure Screen

5.5.4 Flow Calibration Screens

These screens provide the options and indications needed to zero, default, verify, and calibrate the flow sensor as part of the leak check, flow audit, and flow calibration procedures. See **Sections 7.7** and **7.8** for detailed instructions.





Figure 5-10 Flow Calibration Screens

5.5.5 Self-Test Screen

This screen runs the self-test sequence. Press X to exit once it is complete.




Figure 5-11 Self Test Screen

5.5.6 Filter Sensors Screens

These screens provide the options and indications needed to default, verify, and calibrate the filter temperature, filter humidity, and upper and lower pressure sensors. See **Section 7.11** for detailed instructions.

5.5.7 Span Mass Audit Screens

This screen runs the Span Mass Audit. The sequence begins as soon as you enter it. See **Section 7.9** for detailed instructions.

5.5.8 Tape Test Screen

This screen will allow you to verify proper installation and operation of the filter tape and motors. Press the gray MOVE TAPE button to advance the tape. The pass criteria is ≥ 14 mm. The status of the tape, such as OK or if there is a Tape Break error, will also be displayed to the right of the MOVE TAPE button.




Figure 5-12 Tape Test Screen

5.5.9 Nozzle and Count Test Screen

The Nozzle/Count Test screen provides the ability to manually raise and lower the nozzle. Pressing the gray NOZZLE button will cause the nozzle to change state. When the nozzle is in the down position, you can also verify the monitor is beta counting correctly. The frequency for beta counts should be greater than 1000 Hz.




Figure 5-13 Nozzle/Count Test Screen

Counting should only occur when the nozzle is in the down position.

5.5.10 Analog Output Calibration

This screen allows for calibration of the two analog output channels.

The channel field defines whether you are adjusting output number one or two. Tap the green bordered Channel selection box and pick the channel you need to test. The full-scale range will be displayed in the Range value box. If you wish to change the full-scale value, see **Section 5.6.12**.

✓ Analog Output Cal		✕
Channel	1	
Range	0-5.0 V	
Measure	0.0 V	
Adjust	0	
RESET	FINE	<div style="display: flex; justify-content: space-around;"> ▼ ▲ </div>

Figure 5-14 Analog Output Cal Screen

After selecting the output channel, the measure field may be adjusted to maximum or minimum value and the output of the channel confirmed. Just tap the green bordered Measure box and select the desired test output. Verify the actual output using a voltmeter at the appropriate channel terminals on the rear panel of the BAM 1022 PLUS.

If the output is not correct, use the up and down arrow keys to modify the Adjust field. When the FINE/COARSE selection is set to FINE, units will be incremented by one. If it is set to COARSE, the units will be incremented in tens. Tap the button to swap between the options.

Pressing the X key to exit the screen will save any adjustments that have been made. To clear any custom settings and restore the factory defaults, press the gray RESET button.

5.5.10.1 Analog Output Test

To test the analog output channels, select channel number one or two on the top row marked Channel by pressing the green bordered Channel selection box. Now, using the Conc Output field, the output selection may now be modified to any test value in the -15 to +985 range.

✓ Analog Output Test		✕
Channel	1	
Conc Output	+0	
Max Out	5.000 V	
Set Out		
Min Out	0.000 V	

Figure 5-15 Analog Output Test Screen

You'll notice the Min Out and Max Out fields match the zero and full-scale values for the selected output. Between them is the Set Out field, which will update with the expected output based on the concentration selected. Verify the output on the back of the BAM 1022 PLUS matches the Set Out value shown.

5.5.11 Inlet Heater Screen

This screen allows manual operation of the inlet heater assembly. Press ON to turn the heater on and verify the element heats up as expected. Press OFF to turn the heater off; verify it shuts off and then cools down. Exiting this test screen will also turn off the heater if you forget to turn it off when you are done testing.




Figure 5-16 Inlet Heater Screen

5.5.12 Relay Test Screen

This screen allows manual operation of the external alarm relay. Press CLOSE to close the relay contacts. The NO (normally opened) relay on the back of the BAM 1022 PLUS should close its contacts. Press OPEN to reverse its state back to normal conditions.




Figure 5-17 Relay Output Screen

5.5.13 Digital Link Screen

Test digital communications with the BX-597A by entering this screen. The BX-597A firmware version should be displayed when the proper link is established. See **Section 4.6** for details on how to configure the BX-597A sensor, as well as any optional wind sensors that may be connected.




Figure 5-18 Digital Link Screen

5.6 Setup Menu

The Setup Menu grants access to the configuration of most of the operating parameters for the BAM 1022 PLUS. It allows you to change offsets, clear the memory, and set the date and time, and much more. Because of the changes able to be made, the Setup Menu can be password protected if desired. The Sound Volume and Touch Calibration will not be available with the 82564 display.




Figure 5-19 Set Up Menu Screens

Note that the display has a limited amount of space and cannot show all options on one screen. Tap the up and down arrow keys to navigate between the screens shown above.

5.6.1 Set Clock Screen

This is where you set the date and time. Press the green box of the field you wish to modify. The numerical entry keypad will be displayed and allow you to enter the value for that parameter. Once all fields have been entered, press the gray Set button in the lower left corner to set them.





Figure 5-20 Set Clock Screen

5.6.2 Sample Screen

This screen allows you to setup the BAM 1022 PLUS sample options. Conc units allows you to set the concentration units. The two options are $\mu\text{g}/\text{m}^3$ or mg/m^3 . Real-time period allows you to set the real time averaging period for the BAM 1022 PLUS. The available average periods are from 5 to 60 minutes in one minute increments. See **Section 6.4.1** for more details about the Real Time calculation.



Sample	
Conc Units	ug/m3
RealTime Period	15


Figure 5-21 Sample Screen

Note: The MET Average (see **Section 5.6.11**) must be set to an interval less than or equal to the Real Time Period to properly log the Real Time values.

5.6.3 Flow Screen

This screen allows users to select the preferred Standard Temperature value. This is used to calculate the Standard Volume which is used to determine the Standard Concentration value shown on the main operate screen (see **Section 5.1**).

The available options are 0, 20, and 25 Deg C.




Flow	
Standard Temp	25 C

Figure 5-22 Flow Screen

5.6.4 Calibration Screen

This screen allows you to set up certain calibration values for your BAM 1022 PLUS. Background is the mass concentration reading that the BAM 1022 PLUS reads in the absence of any sampled particulate matter and is calculated by performing a zero test (see **Section 7.10**). Regardless of the concentration unit setting, background is always entered in mg/m^3 .



Calibration	
Background	-0.0025
Span Membrane	+0.771

ADVANCED

Figure 5-23 Calibration Screen

WARNING: The span membrane that comes with your BAM 1022 PLUS should never be swapped for one from a different BAM 1022 PLUS. If your span membrane becomes damaged, please contact the factory for instructions on how to replace it.

The Span Membrane is the factory-set expected mass of the reference membrane foil. Each unit's span membrane value is different but is typically near 0.800 mg/cm². Refer to the BAM 1022 PLUS calibration certificate that comes with the monitor. The span membrane value will be listed under the Span Audit Value.

5.6.5 Advanced

To get to the K-Factor setup screen, press the 'Advanced' button found in the calibration setup screen shown in **Section 5.6.4**. Users will be prompted with the warning screen as shown in the image to the right.




Figure 5-24 Advanced Screen Warning

NOTE: Changing the K-Factor should only be changed under advice from the factory, as changing your K-Factor will invalidate the factory calibration that came with the unit.

Pressing the 'Continue' button will allow the user into the Advanced screen, where users may adjust the K-Factor Calibration Constant. Only change this setting with advice from the factory.



Figure 5-25 Advanced Screen

5.6.6 Tape Advance

The BAM 1022 PLUS will advance the filter tape to a clean spot if the pressure drop across the tape becomes too large. The threshold for this action can be set from 50 to 350 mm Hg in one mm Hg increments. Press the green bordered value box and the numerical entry keypad will be displayed. Enter the new pressure threshold value. The default value is set to 100 mmHg.




Figure 5-26 Tape Advance Screen

5.6.7 Clear Memory Screen

The alarm and data logs may be cleared from this screen. Press CLEAR DATA button to clear the data log or press the CLEAR ALARM button to clear the alarm log. A confirmation screen will appear to confirm clearing the memory.




Figure 5-27 Clear Memory Screens

5.6.8 Change Password Screen

Certain menus and options of the BAM 1022 PLUS are password protected. You may use any four-digit password you would like, and this is the screen you need to access to change it. Press the green bordered value box and the numerical entry keypad will be displayed. Enter the new password.

Setting the password to 0000 means no password is used.




Figure 5-28 Change Password Screen

5.6.9 Reports Screen

The hourly report time stamp can be set to mark the data with the time from either the beginning or ending of the hour. For example, if set to beginning, data collected during the hour from 8:00 to 9:00 would be marked as 8:00. Similarly, if that data were collected with ending as the choice, the data time stamp would instead be 9:00. The beginning hourly timestamp only works when the data average period is 1 hour.




Figure 5-29 Reports Screen

The factory default setting for this option is Ending. Press the green bordered value box and a list of the settings available will be displayed. Tap the one you wish to use, and it will be applied.

5.6.10 Station ID Screen

You may enter a four-digit station ID for the BAM 1022 PLUS. Press the green bordered value box and the numerical entry keypad will be displayed. Enter the new location ID value.




Figure 5-30 Station ID Screen

5.6.11 MET Average Screens

If you would like to set an alternate averaging period for parameters other than concentration, you may do so from this screen. Press the green bordered value box and the selection screen shown below right will be displayed. Not all choices are able to be presented at the same time. Use the up and down arrow keys under the displayed options to show additional selections. Tap the one you wish to use and then press the OK button to set it. The available average periods are 1, 5, 10, 15, and 30 minutes or 1 HR (for a one-hour average).




Figure 5-31 Met Average Main Screen





Figure 5-32 Met Average Options Screen

5.6.12 Analog Outputs Screen

There are two analog output channels on the BAM 1022 PLUS. Analog output 1 is the Real Time concentration and output 2 is hourly concentration. These are independently set to one of the following output ranges: 0-1.0 vdc, 0-2.5 vdc, or 0-5.0 vdc.



However, there is only one span scale setting, and it is applied to both channels. It can be set for 0-100, 0-200, 0-500, 0-1,000, 0-2,000, 0-5,000, or 0-10,000 $\mu\text{g}/\text{m}^3$ while the offset can be adjusted to -15, -10, -5, 0, 5 $\mu\text{g}/\text{m}^3$.

Regardless of the concentration units setting, the scaling and offset is always entered in $\mu\text{g}/\text{m}^3$.

To adjust the analog output settings, press the green bordered value box and a list of the settings available will be displayed. Tap the one you wish to use, and it will be applied.

5.6.13 Serial Port Screen

This is where the serial communication settings are configured. Select the required baud rate for RS-232 and RS-485 communications by pressing the green bordered value box. A list of the settings available will be displayed. Tap the one that is needed, and it will be applied.

Serial Port	
RS-232	115200
Flow Control-232	NONE
RS-485	115200

Figure 5-33 Serial Port Screen

The baud rate options are 2400, 4800, 9600, 19200, 38400, 57600, and 115,200. Press the OK key to lock in the choice. See **Section 8.3** for more details about serial communications.

In some cases, remote access using serial to Ethernet converters or modems may require flow control to compensate for slow or noisy connections. In these situations, the RS-232 serial connection can be configured to use XON/XOFF flow control. Flow control is set to NONE by default but can be changed using the Flow Control-232 selection box.

5.6.14 Modbus Screen

Select the active slave Modbus Port: RS-232 or RS-485. The port is accessed from the rear panel (**Section 8.1**) Select the slave Modbus address. Each slave must have a unique address from 1 to 247.


Modbus	
Modbus Port	RS-232
Modbus Address	1

Figure 5-34 Modbus Screen

5.6.15 Ethernet Screen

This screen allows for setting the IP Address, Subnet Mask, and Gateway values to allow the BAM 1022 PLUS to communicate on a local network using a standard Ethernet cable connected to a switch or router.

The values input here should be provided by the site IT department. Set the IP address to 0.0.0.0 for DHCP operation. The IP address port will always be 7500.



Ethernet	
IP Address	0.0.0.0
Subnet Mask	0.0.0.0
Gateway	0.0.0.0

Figure 5-35 Ethernet Screen

5.6.16 Ethernet Config

This screen is used to view the current Ethernet settings of the BAM 1022 PLUS. In addition to the IP Address, Subnet Mask, and Gateway settings (see **Section 5.6.15** for details on changing these values), the MAC Address of the BAM 1022 PLUS can also be viewed here.

Be aware, the IP address port will always be 7500.

Note that this screen is for display purposes only. No changes can be made on this screen.




Ethernet Config	
IP Address	0.0.0.0:7500
Subnet Mask	0.0.0.0
Gateway	0.0.0.0
MAC Address	DE:AD:BE:EF:63:A1

Figure 5-36 Ethernet Config Screen

5.6.17 Ethernet Timeout

The Network Timeout, when enabled, allows the firmware to reset a non-responsive network connection that was not closed properly by an external device, e.g. datalogger. If the activity on the connection is inactive for the specified time in seconds, then the connection will automatically reset. If a connection issue is experienced, it is recommended to set the Ethernet Timeout value to 120 seconds.



Ethernet Timeout	
Ethernet Timeout	0
Time in seconds, 0 for off	

Figure 5-37 Ethernet Timeout Screen

5.6.18 Sound Volume

The touchscreen will beep every time a selection is made, and that volume may be adjusted in this screen. Press the green bordered value box and the numerical entry keypad will be displayed. You may enter a value from 0 – 100 with 100 being very loud and 0 being no beep at all. Any changes made here will not be active until exiting this screen. This will not be available with the 82564 display option.




Figure 5-38 Sound Volume Screen

5.6.19 Touch Calibrate

Press the gray Calibrate button to enter the calibration screen. Simply follow the instructions on the screen to calibrate it. If each step is not completed within five seconds, the test will cancel itself and return to page two of the Setup menu. There is a countdown clock for this feature displayed on each step of the calibration process. This will not be available with the 82564 display option.




Figure 5-39 Touch Calibrate

5.7 Alarms Menu

This screen is used to view time-stamped alarm events with the most recent alarm will be displayed first. Use the up and down arrow keys located at the bottom of the screen to scroll through the alarm log.




Figure 5-40 Alarms Screen

6 OPERATION

6.1 Initial Startup Procedures

Prior to turning on the BAM 1022 PLUS, confirm that all equipment set up procedures, outlined in **Section 4** of this manual, have been completed.

The BAM 1022 PLUS power switch is located behind the rear panel near the bottom of the enclosure on the left-hand side. Upon initial power up, the touchscreen will display a 60 second countdown. The display will audibly beep once every six seconds while counting down. After 60 seconds have elapsed, the monitor will advance the tape one spot and begin sampling.

If tape is missing, or hardware errors (such as a missing sensor) are detected, the monitor will remain idle.

The audible beep is not available with the 82564 display.



6.2 Warm-up Period

If the BAM 1022 PLUS has been deenergized, the mass monitor must warm up for at least one hour before accurate PM measurements can be made. This is because the beta detector must stabilize. Users are encouraged to disregard the first two hourly PM data sets after power is restored.

During the warmup period, maintenance, programming (setup) changes, tests, and data downloads can be performed.

6.3 Commissioning

The following steps should be performed when deploying a BAM 1022 PLUS for the first time:

1. Confirm that the BAM 1022 PLUS settings are correct. Refer to **Section 5.6**.
2. Perform a system Self-Test. See **Section 5.5.5** for details.
3. If an external data logger is being used, ensure that communication is properly established.
4. When using BAM 1022 PLUS analog outputs, verify they correlate to the data logger input. To adjust the analog output, refer to **Section 5.5.10**.
5. If the BAM 1022 PLUS data is being collected remotely, verify the telemetry system is functioning properly.

6.4 Sampling and Measurement Periods

When operating the BAM 1022 PLUS, one must consider two user-selectable parameters:

1. The sampling period is the time between tape advances.
2. The measurement period is the number of one-minute measurements that are combined to produce an integrated measurement.
3. The sampling and measurement periods are independent of one another.

When operating the BAM 1022 PLUS as an EPA-designated PM_{2.5} equivalent method, one-hour measurements are always required. A dedicated one-hour output channel exists on the BAM 1022 PLUS. The *maximum* sampling period when operating the BAM 1022 PLUS in this mode is also currently one-hour. This means that typically the BAM 1022 PLUS will sample for one hour, compute an integrated one-hour result, and then advance the filter tape to begin the next sampling cycle. Under high concentration events such as those during a forest fire, the filter tape may move more frequently than once an hour due to filter tape loading. In such instances, multiple sampling periods may need to be combined to produce the EPA-required one-hour integrated measurement.

The BAM 1022 PLUS can also report integrated PM measurements for time periods less than one-hour. For example, if the sampling period is one-hour, the BAM 1022 PLUS may be configured to report two 30-minute integrated outputs, three 20-minute integrated outputs, four 15-minute outputs, etc, in addition to the one-hour integrated measurement output.

For applications where EPA-designation isn't required, the sampling period may be extended to several hours or longer. The advantage of using this configuration is that a single roll of filter tape can last much longer, for example up to one year if 3-hour sampling periods are used.

When a new sampling cycle commences, the BAM 1022 PLUS will automatically advance the tape to the next sampling spot. The nozzle will be lowered on to the tape and sampling will begin. Flow rates are actively controlled, and beta ray transmission is monitored throughout the cycle. At the end of the sampling event, the BAM 1022 PLUS will shut off the sample pump and repeat the cycle. The gap between measurements is one minute.


6.4.1 Short Term Measurements

The BAM 1022 PLUS always reports an integrated one-hour PM concentration at the top of each hour. Because sampling and measurement are occurring simultaneously, the Real Time concentration period, which is user defined, can be set to various short-term periods as described in **Section 5.6.2** of this operating manual.

The Real Time calculation is a rolling average of the previous few minutes' concentration updated every minute. The number of minutes is defined using the Real Time concentration period setting. For example, if the 15-minute interval is selected, no Real Time value will be displayed until minute 15. It will then display the approximate average of the minute 1-15 time period. At minute sixteen, the average will update and will now only include minute 2-16. This process will repeat every minute until the sample is stopped.

NOTE: The short-term averaging is intended for use as a trend analysis tool. The numerical values recorded are an approximation and cannot be used to calculate the expected hourly concentration value.

Both hourly and user defined average results are stored in the BAM 1022 PLUS data file.



Real-Time Vs. Hourly Concentration Graph

6.4.2 Standard Concentration

Reporting PM_{2.5} concentration data under standard conditions is not a common requirement. To make this reporting easier for users, the BAM 1022 PLUS records the hourly PM concentration in both actual (Conc HR) and standard conditions (ConcS). The Standard Volume is calculated using the Standard Temperature value (see **Section 5.6.3**) and a Standard BP value of 760 mmHg. Once the Standard Volume is known, it is used to determine the Standard Concentration value. This is logged each hour along with the Actual Concentration. The last calculated value for Standard Concentration will be displayed on the Home Screen (see **Section 5.1**).

7 MAINTENANCE, ALARMS and TROUBLESHOOTING

This section provides information regarding routine maintenance, possible alarms, and field troubleshooting procedures.

7.1 Periodic Maintenance

The following table outlines the recommended period for normal maintenance procedures. Several items may need to be attended to more frequently due to site-specific characteristics. It is highly recommended that the instrument operator establish a Standard Operating Procedure (SOP) based on their application.

Table 7-1 Periodic Maintenance

Maintenance Item	Interval	Reference
Replace the filter tape - U.S. EPA PM _{2.5} FEM Applications	4 months	Sec. 4.5
Replace the filter tape (for high concentration areas)	As needed	Sec. 4.5
Leak check	8 Weeks	Sec. 7.7
Nozzle and vane cleaning	8 Weeks	Sec. 7.6.1
Flow audit (verify and/or calibrate flow system)	8 Weeks	Sec. 7.8
Clean PM ₁₀ inlet particle trap	As needed	BX-802 Manual
Clean PM _{2.5} cyclone particle trap	As needed	BX-808 Manual
Verify or set the clock	8 Weeks	Sec. 5.6.1
Mass Audit	6 Months	Sec. 7.9
Background determination	Annually	Sec. 7.10
Internal Nozzle Cleaning	6 Months	Sec. 7.6.2
Replace the Medo pump muffler	6 Months	n/a
Clean pump box and instrument intake filters/fans	6 Months	Sec. 7.6.3
Test analog output voltage (if used)	6 Months	Sec. 5.5.10.1
Rebuild Medo AC pump (BX-126/127)	As needed	680839-9800 Guide
Rebuild Gast AC pump (BX-121/122)	As needed	680828-9800 Guide
Empty PM ₁₀ inlet water jar	As needed	BX-802 Manual

7.2 Alarms

In the event a measured parameter or sequence is not within design specification, the BAM 1022 PLUS will generate an alarm. These alarms can be monitored via the alarm log, output files or the alarm relay. A list of alarms is detailed below.

An alarm is indicated and logged at the time it occurs. The resolution time is not recorded. See **Section 5.7** for an explanation of viewing alarms through the BAM 1022 PLUS panel display.

NOTE: If multiple errors occur in the same data period, the stored alarm code will be the sum of the two individual codes.

NOTE: A concentration value of 99.999 mg/m³ or 99999 µg/m³ is an invalid concentration measurement and is due to an appropriate alarm condition.

To determine which codes are being summed, note the largest code number that is less than the value stored. This will be the first code being summed. Subtract that from the stored value to determine the second code. Repeat this process until all codes are known. For example, if 264 is stored, the largest code beneath that value is 256. The difference between 264 and 256 is 8. This means the two codes are 256 and 8.

Table 7-2 Alarm Code Descriptions

Code	Description	Cause
1	Tape Break	No tape movement was detected during the tape move process.
2	Beta Detector	The event occurs when the Beta detector count rate is less than 500 Hz during the sampling cycle.
4	Sensor Range	The event occurs when an analog sensor reading (AT, RH, BP, UPPER, LOWER, FT, FRH) is outside the designated limits.
8	Tape Advance	The event occurs when the pressure drop across the tape exceeds the Tape Advance Pressure setting.
16	Flow Failure	The event occurs when the sample flow is less than 1.0 SLPM for greater than 1 minute. The event occurs when the sample flow is +/-10% out of regulation for 1 minute. The event occurs when the sample flow is +/-5% out of regulation for 5 minutes.
32	Nozzle Failure	The event occurs when the nozzle fails to move and/or stop at the up or down position. The event will also occur when the foil device is still inserted at start of operation.
64	Digital Link Failure	The event occurs when communication with the BX-597A sensor has ceased for greater than 10-seconds.
128	Power Failure	The event occurs for a power cycle, or a micro-processor reset.
256	Short Sample	The event occurs when the first sample cycle is less than 1-hour.
512	Maintenance	The event occurs when the user stops normal operation.

7.3 Hardware Failure Screen

This screen is presented to the user when a hardware failure occurs with the type of alarm (Tape Break, Sensor Range, Flow Failure, Nozzle Failure, Digital Link Failure) indicated in red text. Pressing the gray ALARMS button will present the View Alarms screen. See **Section 5.7** for more information about viewing alarms.




Figure 7-1 Hardware Failure Screen

7.4 Sensor Out of Range Event

A Sensor Range alarm occurs when one of the sensors listed in the table below is reading outside of its designated limit.

Each sensor, along with its limits, is shown in the following table. The Stop column indicates whether the error will cause the BAM 1022 PLUS to stop sampling.

Table 7-3 Valid Sensor Ranges

Sensor	Minimum	Maximum	Stop
AT	-50	70	Yes
RH	0	100	No
BP	375	825	Yes
UPPER	228	818	Yes
LOWER	228	818	Yes
FT	-40	60	Yes
FRH	0	98.9	No
BOX	-40	60	No
BETA	500	20000	Yes

7.5 Alarm Relay

There is one alarm relay on the BAM 1022 PLUS to indicate to an external device that an alarm has occurred. It is a normally open (NO) contact that closes whenever there is a pending alarm.

The short sample and tape advance alarms do not affect the alarm relay. See **Section 5.6.13** for testing details.

7.6 Cleaning

7.6.1 Nozzle and Vane Cleaning

Over time, a gradual build-up of filter tape debris and particulate may form on the nozzle and vane sealing surfaces. Follow the steps below to clean particulate filter tape debris from these surfaces.

Required Tools: Cotton Tipped Swabs (Met one Instruments Part No. 995217)
Isopropyl Alcohol

Canned Air (a.k.a. Compressed Air Duster) with Tube

Suggested Interval: Upon filter tape replacement (8 weeks).

Use the following steps to clean the nozzle and vane assembly:

1. Navigate to the Test>Leak Test menu and raise the nozzle, if needed.
2. Remove the BAM 1022 PLUS filter tape.
3. Thoroughly clean the nozzle seal and vane with a cotton swab dipped in alcohol. Do not use any sharp tools. Allow the alcohol to dissolve hardened deposits.

Since the beta detector is located beneath the vane, prevent debris from falling through the holes.

4. If debris falls through or is found beneath the vane, carefully clean the cavity with a blast of compressed air.
5. Re-install the BAM 1022 PLUS filter tape per **Section 4.5** and perform a leak check as instructed in **Section 7.7**.




Figure 7-2 Nozzle Seal Cleaning




Figure 7-3 Vane Cleaning




Figure 7-4 Filter Tape Path

7.6.2 Internal Nozzle Cleaning

The inside of the sample nozzle should be periodically cleaned to remove particulate which may have settled on internal surfaces. This cleaning prevents a buildup of debris, which could fall out of the nozzle and on to the tape (causing undesired positive concentration spikes).

Required Tools: Canned Air (a.k.a. Compressed Air Duster) with Tube

Suggested Interval: Every 6 months.

Use the following steps to clean the nozzle's internal surfaces:

1. Go to the Operate menu and select Stop Sample to stop the current sample.
2. Remove the size selective inlets and smart heater from the sample tube pull the sample tube out of the BAM 1022 PLUS inlet receiver.
3. Go to the Test > Tape Test menu and press the gray TEST TAPE button to advance the filter tape to a clean spot.

4. Gently slide the canned air tube down the inlet receiver on top of the BAM 1022 PLUS. Supply multiple short blasts of air, while moving the canned air tube from side to side to blow on all surfaces inside the inlet. See picture below.




Figure 7-5 Nozzle Cleaning

5. Go to the Operate menu and select Start Sample to start a new sample. Allow the pump to run for approximately 1 minute and then stop the sample.
6. Go to the Test > Tape Test menu and advance the filter tape to allow inspection of the sample spot.
7. If debris is still present, repeat steps 3 -6.
8. Reinstall the inlet tube, smart heater, and size selective inlets before sampling is resumed.

7.6.3 Clean Intake Fans and Filters

The instrument intake fan is mounted above the upper shelf. The Pump Box fan is mounted inside the Pump Box.



Instrument Intake Fan



Pump Box Fan

The intake fans are protected by a removable fan guard and filter. Remove the fan guard and filter. Use compressed air to clean debris from the fan blades and from the removable fan guard. The filter can be hand washed but must be completely dry before reinstallation.



Intake Fan with Fan Guard/Filter Removed



Intake Fan with Fan Guard/Filter Installed

Note: The GAST pump has an internal thermal trip device that will prevent pump operation when overheated. An inoperable fan or obstructed fan filter can cause instrument malfunctions.

7.7 Leak Check

The leak check procedure, described below, must be used on the BAM 1022 PLUS because of the nature of the filter tape (P/N 460185)

Required Tools: Leak Check Valve (Met One Instruments Part No. BX-305 or BX-302), Nozzle Seal Tool (Part No. 7440), acclimated and calibrated Flow Calibrator, e.g. Swift 25.0.

7.7.1 Filter Tape Leak Test

Use this procedure to assess the leak rate at the nozzle to tape interface. Remove the BX-305 from the inlet and install a calibration transfer standard (CTS).

1. Navigate to the TEST>LEAK TEST menu.
2. Press the Nozzle UP button to raise the nozzle.
3. Remove the filter tape from the nozzle area.
4. Insert the Nozzle Seal tool **with the hole positioned beneath the nozzle.**



Figure 7-6 Nozzle Seal Tool

5. Press the PUMP ON button to start the pump
6. Allow at least 2-3 minutes for the flow to fully stabilize. When the flow rate stabilizes, write down the CTS flow rate value. This is the “Without Tape” value.

NOTE: If after 5 minutes, the flow still has minor fluctuations, estimate the average flow rate and use that for the “Without Tape” value.

7. Stop the pump and raise the nozzle.
8. Remove the Nozzle Seal Tool.
9. Reinstall the filter tape below the nozzle and press the Nozzle Down button to lower the nozzle onto the tape.

10. Press the PUMP ON button to start the pump
11. When the flow rate stabilizes, write down the CTS flow rate value. This is the “With Tape” value.
12. Stop the pump and raise the nozzle.
13. Subtract the “With Tape” value from the “Without Tape” value using the following equation:

7.7.1.1 Without Tape – With Tape = Leak Rate

The result should be a positive value of 0.3 LPM or less. A typical example might look like this: 16.71 LPM – 16.58 LPM = 0.13 LPM

- a. If the difference is 0.3 LPM, or less, the leak test passes. Record the results (as needed), remove all test equipment, and resume normal sampling operations.
- b. If the difference is greater than 0.3 LPM, an out of tolerance leak exists at the nozzle / tape interface. Thoroughly clean the nozzle and vane area and then perform this test again. Repeat this test. If after a couple of attempts this test still fails, contact the Met One Instruments, Inc. service department (see **Section 1.2**) for assistance.

7.7.2 Total System Leak Test

This procedure will create a positive seal at the nozzle/vane interface and test the remainder of the flow system for leaks.

1. Navigate to the TEST>LEAK TEST menu
2. Press the NOZZLE UP button to raise the nozzle.
3. Remove the filter tape from beneath the nozzle and insert the Nozzle Seal Tool **with the hole positioned beneath the nozzle** and then press the NOZZLE DOWN button.
4. Install the BX-305 (or BX-305) on the inlet and verify the valve is in the **open** position.
5. Press the PUMP ON button. The BAM 1022 PLUS will start the pump.
6. Allow the flow rate to stabilize at approximately 16.67 LPM.
7. Press the LEAK ON button to prevent automatic flow controller adjustments.
8. Slowly close the BX-305 or BX-302 valve to seal the inlet (see Figure 7-7).



Figure 7-7 BX-305 Leak Check Tool

9. The pump flow rate should drop below 0.3 LPM.
 - a. If the flow rate is 0.3 LPM or less, the leak check is satisfactory. Slowly open the BX-305 or BX-302 valve. Proceed to **Section 7.8**.
 - b. If the flow rate is greater than 0.3 LPM, then there is a leak somewhere in the system. Conduct the Lower System Leak Test in **Section 7.7.3** to locate the leak.

7.7.3 Lower System Leak Test

This procedure will split the flow system at the nozzle / vane interface. With this seal in place, only the portion of the flow system downstream of this location will be placed under vacuum and tested for leaks.

1. If running, press the PUMP OFF button to turn off the pump. Then, press the NOZZLE UP button to raise the nozzle.
2. Insert the Nozzle Seal Tool so that the solid portion of the tool is positioned beneath the nozzle (See Figure 7-8) and then press the NOZZLE DOWN button. See the image below.



Figure 7-8 Nozzle Seal Tool, Lower System Leak Test

3. Press the PUMP ON button followed by the LEAK ON button. The BAM 1022 PLUS will start the pump and prevent automatic flow controller adjustments.
4. The pump flow rate should drop below 0.3 LPM.
 - a. If the flow rate is 0.3 LPM or less, the leak check is satisfactory. This confirms that the leak is above the nozzle. Investigate all mating connections and O-rings in the flow path before the nozzle / vane interface to locate and correct the leak.
 - b. If the flow rate is greater than 0.3 LPM, then there is a leak downstream of the nozzle. Investigate all mating connections and O-rings in the flow path after the nozzle / vane interface to locate and correct the leak.
 - c. Once resolved, repeat the steps listed in **Section 7.7** to verify the flow system integrity.
5. Press the PUMP OFF button to stop the pump.

7.8 Flow Audit and Calibration

The accuracy of the BAM 1022 PLUS flow control system should be periodically verified. If the flow, temperature, or pressure sensors are not operating within desired specification, they should be calibrated.

Required Tools: Certified Calibration Transfer Standard (CTS)
(e.g. Flow Calibrator, Met One Instruments Part No. Swift 25.0)

Minimum Suggested Interval: Complete calibration upon commissioning.
8 weeks minimum or after filter tape replacement.

All calibration transfer standards should be certified to the following criteria, and have a valid certificate of traceability to NIST standards:

Table 7-4 Calibration Equipment Acceptance Criteria

Transfer Standard	Acceptance Criteria
Flow Rate	± 2% of NIST Traceable Standard
Ambient Temperature	± 0.1° C Resolution ± 0.5° C Accuracy
Barometric Pressure	± 1 mmHg Resolution ± 5 mmHg Accuracy

If a flow audit is desired (and not a full calibration) the same procedure detailed in this section is followed, but no changes are made; the results are observed and recorded only. A flow audit confirms operation of the flow system without making any changes. This may be necessary to validate collected data.

During verification of the BAM 1022 PLUS flow control system, the following acceptance criteria should be maintained.

Table 7-5 Flow Control System Acceptance Criteria

Parameter	Acceptance Criteria
Flow Rate	± 4% of transfer standard
Ambient Temperature	± 2° C of transfer standard
Barometric Pressure	± 10 mmHg of transfer standard

Use the following steps to verify and calibrate sensors associated with the BAM 1022 PLUS sample flow control system.

1. Make certain that the BAM 1022 PLUS has warmed up for at least 60 minutes prior to performing calibrations. Also, allow the calibration transfer standard (CTS) to equilibrate to ambient conditions for no less than 30 minutes.
2. Go to the Operate menu and select Stop Sample to stop the current sample.
3. Remove the size selective inlet(s) from the sample tube and install the calibration transfer standard (CTS).
4. Enter the Test > Ambient Temperature screen.
5. Compare the BAM 1022 PLUS temperature measurement and CTS temperature reading by placing the tip of the CTS temperature probe into the upper area of the BX-597A radiation shield directly next to the BX-597A temperature sensor
6. If the BAM 1022 PLUS temperature sensor exceeds the criteria listed in the table above, press the gray DEFAULT button to remove any previous offsets. If the temperature now passes, go to step 8.

7. If the temperature still needs to be adjusted, press the green bordered value box and the numerical entry keypad will be displayed. Enter the CTS value in the Standard field and press OK to return to the Ambient Temperature screen. Press the gray CALIBRATE button to enter the new calibration offset.
8. Return to the TEST menu and go to the Ambient Pressure screen.
9. Compare the BAM 1022 PLUS pressure measurement and CTS pressure reading.
10. If the BAM 1022 PLUS pressure sensor exceeds the criteria listed in the table above, press the gray DEFAULT button to remove any previous offsets. If the pressure now passes, go to step 12.
11. If the pressure still needs to be adjusted, press the green bordered value box and the numerical entry keypad will be displayed. Enter the CTS value in the Standard field and press OK to return to the Ambient Pressure screen. Press the gray CALIBRATE button to enter the new calibration offset.
12. Return to the TEST menu and select the Flow Calibration menu (see **Section 5.5.4**).
13. On the Zero Flow test screen, verify the Flow value indicates 0.00 LPM. If it does not, press the gray ZERO button and confirm that the Flow value changes to 0.00 LPM.
14. Press the gray CONTINUE button to proceed to the Flow Calibration screen. The pump will start automatically and adjust flow to the 16.7 LPM test point.
15. Press the green bordered value box the flow rate test set point selection will appear.
16. Select the 14.0 LPM set point and then press the OK button. The display will return to the Flow Calibrate screen and adjust the flow to the new test point.
17. Allow the BAM and CTS reading to stabilize (at least one minute) and then compare the BAM 1022 PLUS flow measurement and CTS flow reading.
18. If the BAM 1022 PLUS flow rate exceeds the criteria listed in the table above, press the gray DEFAULT button to remove any previous offsets for all three flow settings. If the flow rate now passes, skip the next step.
19. If the flow rate still needs to be adjusted, press the green bordered value box and the numerical entry keypad will be displayed. Enter the CTS value in the Standard field and press OK to return to the Flow Calibrate screen. Press the gray CALIBRATE button to enter the new calibration offset.
20. Press SET to apply the change. When setting the 16.7 LPM flow rate, the SET option will change to read CALIBRATE.

21. Repeat steps 15 through 18 above for the 17.5 LPM flow rate.
22. Repeat steps 15 through 18 above for the 16.7 LPM flow rate.
23. Return to the Home Screen and remove the CTS from the inlet tube and replace the size selective inlet(s).
24. Resume normal sampling operations.

7.9 Span Mass Audit

The Span Mass Audit screen, located in the Test menu, is used to verify the performance of the BAM 1022 PLUS. A zero and span foil (included in the BAM 1022 PLUS accessory kit) will be required to complete this procedure. When this screen is accessed, the nozzle will be raised, and you will be instructed to enter the zero-calibration foil.




Figure 7-9 Span Mass Audit Warning

WARNING: The filter tape must be loaded for this test.

Insert the zero foil **above the filter tape** between the nozzle and vane, with the label facing up. Take care to minimize tape movement.



Figure 7-10 Zero Span Foil Installation



Figure 7-11 Span Foil Installed

When the zero foil is detected, the nozzle will automatically lower on to the foil and the four minute measurement will commence. After four minutes, the nozzle will be raised, and the screen will instruct you to remove the zero foil. Remove the zero foil. Take care to minimize tape movement.

Span Mass Audit	
	SAMPLING
Zero	71221
Time	232 Sec

Figure 7-12 Span Mass Audit Sampling

Span Mass Audit	
Remove Zero Foil	

Figure 7-13 Remove Zero Foil

Once removed, the display will change to list the current span foil setting. Compare this value to the value on the calibration certificate. It should be correctly entered at the factory. If the values do not match, tap the green bordered span value field, and enter the value listed on the calibration certificate now. Press the gray CONTINUE button to continue to the next step.

Span Mass Audit	
Span	+0.673
CONTINUE	

Figure 7-14 Span Mass Audit Value

The display will instruct you to insert the span foil. Insert the span foil **ABOVE the filter tape**, with the label facing up. Take care to minimize tape movement. When the span foil is detected, the nozzle will automatically lower on to the foil and the four-minute measurement will commence.




Figure 7-15 Insert Span Foil



Figure 7-16 Span Foil Installed Above Tape

After four minutes the screen will change and display the results of the audit. The measured mass will be listed on the top, the programmed span value will be in the middle, and the error between the two will be listed on the bottom. These results are not automatically logged into the unit; they should therefore be written down.

✓ Span Mass Audit		✕
Mass	0.592	
Span	0.598	
Error	-1.1 %	

Figure 7-17 Span Mass Audit Results

If the error is greater than +/- 5%, the audit has failed. The error is usually caused by tape movement during the insertion and removal of the zero and span foils. If a large error occurs, redo the test while paying attention to minimizing tape movement. If the test continues to fail, see **Sections 7.6** and **7.6.2** for cleaning instructions. If the audit continues to fail, contact the Met One Service team for assistance.

Press the X button in the upper right corner to exit the audit. The nozzle will be raised you will be instructed to remove the span foil.




Figure 7-18 Span Foil Test Complete

Remove the foil and the display will automatically return to the Test menu.

7.10 Background Determination (Mass Offset)

It is recommended that the BAM 1022 PLUS undergo a background test upon initial deployment, annually, and after any major repairs have been performed. Background tests should be used to verify that your BAM 1022 PLUS is meeting performance specifications.

When the BAM 1022 PLUS is set up for the first time, a minimum of 48-72 valid 1-hour zero-test data points should be collected in order to accurately determine the Background value. Subsequent periodic zero tests may be performed with fewer (at least 24) 1-hour values, but this could result in a less accurate Background calculation.

It is recommended that the BAM 1022 PLUS be operated for at least 24-hours before commencing the zero-filter test. A leak check and flow check should be performed before proceeding on to the following steps for the zero-test. Although it is not necessary to reset the existing Background value to zero for the purpose of conducting the zero-test, doing this could minimize the chance of a miscalculation.

Notes:

- For best results, the zero filter background test should be performed during a period of stable weather conditions.
- It is recommended that the Inlet Cover (Met One Instruments Part No. 81418) is installed on the BX-302 to prevent water intrusion and light from entering the inlet during background testing. Refer to the current BX-302 manual at <https://metone.com/support-documents/>.
- The zero-filter cartridge should be replaced if there are any obvious signs of discoloration due to aging or the aspiration of water. See **Section 10** for ordering details.

Required Tools: Zero Filter (Met One Instruments Part No. BX-302) with Inlet Cover

Use the following steps to conduct a zero-filter background test and set the mass offset.

1. Ensure that the BAM 1022 PLUS has been flow-calibrated and that leaks are not present.
2. Go to the Operate menu and select Stop Sample to stop the current sample.
3. Remove the size selective inlet(s) from the sample tube and install the BX-302 assembly.



BX-302 Zero Filter Assembly

4. Verify that the zero-filter leak valve is in the open position.
5. Go to the Setup menu and select Calibration.
6. Set the Background value to zero (see **Section 5.6.4** for details).
7. Exit the Background menu, go to the Operate menu, select Start Sample, and begin sampling.
8. For the initial zero test, allow the BAM 1022 to sample for 48-72 consecutive hours, not counting the warm-up period. For the zero-test to be valid, no errors should be logged either during the sampling period. For subsequent zero tests the user may decide to use fewer valid data points (such as 24 for example).
9. Calculate the average of the hourly BAM 1022 concentration measurements to the nearest $0.1 \mu\text{g}/\text{m}^3$.
10. The new Mass Offset value is the negative of the hourly concentration average calculated in Step 9. For example, if the average = $0.46 \mu\text{g}/\text{m}^3$, the new Mass Offset would be $-0.46 \mu\text{g}/\text{m}^3$. Since all Background values are entered in units of mg/m^3 , you would round to the fourth decimal place and use $-0.0005 \text{mg}/\text{m}^3$.
11. Return to the Setup menu and select Calibration.
12. Enter the new Background value.

13. Go to the Operate menu and select Stop Sample to stop the current sample, if the monitor is still sampling.
14. Remove the zero filter from the inlet tube and install the size selective inlet(s)
15. Resume normal sampling.

NOTES:

To determine the hourly zero noise and hourly lower detection limit, calculate the standard deviation of the hourly PM concentrations (the values used in step 9 above). The standard deviation (σ) should be less than or equal to $1.6 \mu\text{g}/\text{m}^3$. The hourly detection limit is defined as two times the standard deviation (2σ).

If the standard deviation is greater than $1.6 \mu\text{g}/\text{m}^3$, the cause should be investigated. Contact your local Met One Instruments representative for assistance.

7.11 Filter Sensor Audit

The four filter sensors are all verified at a single test point. The temperature and relative humidity sensors are both audited with the pump running so that air flows across the sensors and provides an accurate indication. Both the upper and lower pressure sensors are audited with the pump off so that they will display the ambient pressure value.

Filter Sensors	
Filter Sensor	TEMPERATURE
BAM 1022	26.0 C
Reference	+26.2
<div style="display: flex; justify-content: space-around;"> DEFAULT CALIBRATE </div>	

Figure 7-19 Filter Sensor Main Audit Screen

If factory default values are ever needed, press the gray DEFAULT key. This will remove all field applied calibrations for the selected sensor and restore the factory default values.

NOTE: Never calibrate the temperature or relative humidity sensors if the inlet heater has been operating recently. The pump should be run for at least two hours after turning off the inlet heater before attempting to calibrate these sensors.

7.11.1 Filter Temperature and Relative Humidity Sensors

1. Navigate to the Test> Filter Sensor menu.
 - a. The pump will start and the menu will display the filter temperature sensor test interface first. Allow the pump to run for at least ten minutes to allow the sensor to equilibrate with the reference standard (see step 2 below).
 - b. Verify that the nozzle automatically raises if it is in the down position. It must be in the up position for these tests.
2. Place the AT standard as close as possible to the nozzle opening. Allow at least ten minutes for the standard to equilibrate with the filter sensor while the pump is running.
3. Verify the BAM 1022 PLUS reading matches the standard within +/- 1 deg C.

- a. If the sensors do not match within specification, press the green bordered Standard value field and enter the value reported by the standard.
 - b. Press the gray CALIBRATE button to set the new calibration.
4. Tap the green bordered Filter Sensor field.
5. Locate the HUMIDITY option in the sensor list. You may need to use the up and down arrow keys to view the entire list.
6. Tap the HUMIDITY option to select it. The option should turn green. Press the OK button to exit out of the sensor selection list and return to the sensor test screen.
7. Place the RH standard as close as possible to the nozzle opening. Allow at least ten minutes for the standard to equilibrate with the filter sensor while the pump is running.
8. Verify the BAM 1022 PLUS reading matches the standard within +/- 4%.
 - a. If the sensors do not match within specification, press the green bordered Standard value field and enter the value reported by the standard.
 - b. Press the gray CALIBRATE button to set the new calibration.
9. When filter sensor testing is complete, press the X key to return to the Test menu. If pressure sensor testing also needs to be performed, go to **Section 7.11.2**.

7.11.2 Filter Pressure Sensors

1. Navigate to the Test> Filter Sensor menu.
 - a. The pump will start and the menu will display the filter temperature sensor test interface first.
 - b. Verify that the nozzle automatically raises if it is in the down position. It must be in the up position for these tests.
2. Tap the green bordered Filter Sensor field.
3. To calibrate the upper pressure sensor, locate the UPPER PRES option in the sensor list. You may need to use the up and down arrow keys to view the entire list.
4. Tap the UPPER PRES option to select it. The option should turn green. Press the OK button to exit out of the sensor selection list and return to the sensor test screen.
5. Verify the pump turns off.
6. Place the pressure standard as close as possible to the nozzle opening. Allow at least ten minutes for the standard to equilibrate with the filter sensor.
7. Verify the BAM 1022 PLUS reading matches the standard within +/- 5 mmHg.
 - a. If the sensors do not match within specification, press the green bordered Standard value field and enter the value reported by the standard.

- b. Press the gray CALIBRATE button to set the new calibration.
8. Tap the green bordered Filter Sensor field.
9. To calibrate the lower pressure sensor, locate the LOWER PRES option in the sensor list. You may need to use the up and down arrow keys to view the entire list.
10. Tap the LOWER PRES option to select it. The option should turn green. Press the OK button to exit out of the sensor selection list and return to the sensor test screen.
11. Verify the pump remains off.
12. Place the pressure standard as close as possible to the nozzle opening. Allow at least ten minutes for the standard to equilibrate with the filter sensor.
13. Verify the BAM 1022 PLUS reading matches the standard within +/- 5 mmHg.
 - a. If the sensors do not match within specification, press the green bordered Standard value field and enter the value reported by the standard.
 - b. Press the gray CALIBRATE button to set the new calibration.
14. If filter sensor testing is complete, press the ESC key to return to the test menu. If temperature and RH sensor testing also needs to be performed, go to **Section 7.11.1**.

7.12 Basic Problems & Solutions

The following table contains information on some of the more common problems that may be encountered, and some steps to identify and remedy the problems. Met One Instruments welcomes customer suggestions for new items to include in this section of future manual revisions. If the solution cannot be found in the following table, then contact one of our expert service technicians for help in resolving your problem.

Problem:	The mass monitor won't start a measurement cycle.
Cause/Solution:	<ul style="list-style-type: none"> • The mass monitor will not start a measurement cycle if it detects a hardware failure, such as low beta count signal, nozzle failure, pressure sensor failure, or pump failure. • The mass monitor will not start a cycle if the ambient temperature sensor is not connected. • The mass monitor will not start a cycle if the filter tape is not installed correctly. • The mass monitor will usually display an error message on the display if it cannot start a cycle. • If the mass monitor is left in a SETUP or FIELD CALIBRATION screen, it should still try to start a cycle after several minutes of inactivity, unless a failure is detected.
Problem:	The analog output voltage concentration readings are full-scale.
Cause/Solution:	<ul style="list-style-type: none"> • The mass monitor will force the analog output to the full scale voltage to indicate an error. Review the History / Alarm log to view any possible errors. • The full-scale analog output is usually scaled to represent 1.000 mg/m³. If this concentration is recorded by an external data logger which is measuring the analog output, then either there is an error in the mass monitor, or the particulate concentrations have exceeded the range of the analog output.
Problem:	The mass monitor records frequent "Tape Advance" errors.
Cause/Solution:	<ul style="list-style-type: none"> • This usually indicates that the filter tape is automatically advancing in response to being clogged due to heavy particulate loading. • When hourly PM readings repeatedly exceed 100 µg/m³ more frequent tape advance intervals may be required.

Problem:	The concentration indicates negative values.
Cause/Solution:	<ul style="list-style-type: none"> • It is possible for the mass monitor to occasionally record negative hourly values if the actual particulate concentration is very low, such as $-3 \mu\text{g}/\text{m}^3$. This is because the mass monitor has an hourly random noise band of several micrograms. • If the mass monitor is reading large, negative numbers hour after hour, it is probably punching holes in the filter tape. These holes can be very small and hard to see. This is almost always caused by debris on the nozzle or vane. Clean the parts. • The real-time averages of the mass monitor are considerably noisier than the hourly measurements. These noise spikes may indicate negative concentrations unless the true concentrations are high. • The noise performance of the mass monitor may be audited. Met One Instruments supplies the BX-302 zero filter kit for auditing the zero readings of the mass monitor.

Problem:	The airflow won't regulate at the correct rate of 16.7 LPM.
Cause/Solution:	<ul style="list-style-type: none"> • This usually indicates that the air pump is losing vacuum capacity due to wear. • Check for leaks at the nozzle. This will often cause the inlet flow to be low even though the flow sensor is measuring the correct flow rate. This is because the flow sensor is downstream of the filter tape and nozzle. Clean the nozzle and vane. • Perform a flow calibration. If the flow regulates at the lower calibration point, but not the higher point, the pump is probably worn out or there is a leak. • The gray plastic pump mufflers used on the vacuum pump clogs up after several months. Replace it every six months. • Check the inlet and PM heads for obstructions.

Problem:	The mass monitor has flow leaks, even after cleaning the nozzle and vane.
Cause/Solution:	<ul style="list-style-type: none"> • The nozzle may be sticking. Verify that the nozzle up/down motion is smooth and complete. If the nozzle is sticky or gritty, it will not seal properly. • Check the O-rings on the sharp-cut cyclone (if used). These frequently leak. • Check for bad O-rings on the inlet receiver. • Check all of the push-in air fittings inside the mass monitor.

Problem:	The mass monitor will not pass the span membrane test.
Cause/Solution:	<ul style="list-style-type: none"> • This often just indicates the membrane foil surface is dirty or damaged. It can be cleaned with distilled water. Damaged membranes must be replaced. • If the membrane is in good condition, but the mass monitor fails span tests, then the most common problem is debris on the beta detector window. Carefully blow through the vane with canned dusting air to blow debris off of the detector window and try again. • If the detector is clean and the membrane is in good condition, then failed span tests can indicate that the detector is wearing out. Contact the Service Department.

Problem:	The clock settings are lost when the mass monitor is powered down.
Cause/Solution:	<ul style="list-style-type: none"> • There is a small coin cell battery inside the mass monitor that maintains the clock and other settings when the mass monitor is powered off. After several years the battery may need to be replaced if the clock resets when the mass monitor is powered off. • It is normal for the clock to drift as much as 2 minutes per month.

8 DATA COLLECTION and COMMUNICATIONS

The BAM 1022 PLUS is capable of relaying information to and from external devices using analog outputs, digital inputs and outputs, RS-232 serial communications, USB serial, Ethernet and USB flash drive.

8.1 Analog & Digital I/O

Terminal connections on the rear panel of the BAM 1022 PLUS are available for communicating with data acquisitions systems by means of analog and digital inputs and outputs.

The following is a detailed map of the terminal block connections:




Figure 8-1 Terminal Block Connections

The BX-597A Digital Sensor connects to the top sensor RS485 Sensor Network terminal connections. The second set of RS485 terminal connections is for an optional wind sensor, if used (see **Section 11.2**).

The pump and heater control wires connect to the appropriately labeled terminals in the Contact terminals below the Sensor Network terminals.

The Alarm Relay output is located on the bottom of the left set of terminals. The contact is rated for 1 A at 125 VAC or 60 VDC maximum.

Analog Outputs 1 and 2 can be configured as either 0-1, 0-2.5, or 0-5 VDC using the Analog Outputs setup screen. Analog output 1 is the real-time concentration and output 2 is hourly concentration.


The RS232 COM terminals provide a RS-232 serial output data to a nearby datalogger or telemetry device.

The Fan terminals are used to power the upper enclosure fan.

The RS485 COM connections at the bottom of the right set of terminals provide RTS-485 serial output data to a nearby datalogger or telemetry device.


8.2 Transfer Data to USB Flash Drive

The BAM 1022 PLUS can copy data files directly to a user-supplied USB flash drive. For compatibility, USB flash drives must be formatted with the FAT or FAT32 file system. This drive must be installed in the Type-A USB port located behind the front door, in the upper right corner of the tape transport. This USB port is not used for any other purpose.



Copy to USB Drive	
Days	99
Files	ALL
COPY	

Figure 8-2 Copy Data to USB Main Screen



Copy to USB Drive	
Status	COPY COMPLETE
Progress	100 %
Error	

Figure 8-3 Data Copy to USB Complete

1. Enter the OPERATE > TRANSFER DATA menu.
 - a. The Days field determines how many records you download. If you wish to change the number of days being copied, press the green bordered value box and the numerical entry keypad will be displayed. Enter the number of days between 001 and 999.
 - b. The FILES field determines whether you download all of the stored record types or only the user selected records. The USER files are ones which are used for all routine data collection purposes. The ALL option includes additional factory diagnostics files which are only used if data is being sent to Met One Instruments for factory support. The default setting is USER. If you need to change this field, press the green bordered value box and a list of the options available will be displayed. Tap the one you wish to use, and it will be applied.
2. Locate the USB slot above the tape supply spool and insert a USB memory stick into it.
3. Press the gray COPY button to copy the selected data to the USB memory stick.
4. When the COPY COMPLETE message is displayed, remove the USB memory stick and close the front door of the BAM 1022 PLUS.

Copy errors may be caused by an incompatible or substandard USB drive.

8.3 Serial Communications

The BAM 1022 PLUS can communicate via serial commands using RS-232, USB Serial, or Ethernet. The monitor only allows one of these connections at a time. These connections allow users to both download data and operate the instrument.

The default RS-232 settings are as follows:

Baud Rate: 115,200
Data Bits: 8
Parity: None
Stop Bits: 1
Flow Control: None

If using the 82629 RS-232 cable with DB9 connector, wiring connections are as follows:

Table 8-1 Serial to Terminal Block Wiring

82629 WIRE COLOR	BAM 1022 PLUS TERMINAL NAME
RED	TX
BLACK	RX
CLEAR	GND
WHITE/BROWN	SHIELD

See **Section 5.6.15** for details on configuring the IP address for Ethernet communications.

8.3.1 Terminal and Escape Commands Using the 7500 Protocol

The BAM 1022 PLUS supports a system of ASCII based terminal commands and Escape commands that can be used to manually collect data records or to remotely change some of the settings in the instrument through the serial port. These commands can be sent to the instrument through the “Direct Connect” terminal window tab in Comet (or through HyperTerminal or similar terminal programs). They can also be programmed into a digital data logger or similar automated system. Most of these functions are intended primarily for use with advanced or remote data collection systems and are not usually used for routine data collection purposes. The Met One Instruments 7500 Protocol commands can be used in either Terminal Mode or Escape Command Mode. For a detailed listing of all commands and their formats, consult the BAM 1022 PLUS 7500 document available from the Met One Instruments website:

<https://metone.com/support-documents/>

8.3.1.1 Terminal Mode

The BAM 1022 PLUS must be placed in Terminal Mode to use the Terminal Mode command set. From any command prompt (such as the terminal window in the Comet software), send three <cr> carriage returns (“Enter” key on a standard keyboard) through the serial port. The instrument will respond with an asterisk (*) indicating that it is in Terminal Mode. Any terminal command may now be sent to the instrument.

NOTE: The instrument will time out of Terminal Mode after two minutes of serial port inactivity, and Terminal Mode will have to be reinitiated before more commands can be sent. Terminal Mode commands are echoed back to the terminal program.

1.1.1.1 Escape Command Mode

Escape commands do not require the BAM 1022 PLUS to be in Terminal Mode. The command strings are slightly more complicated, but there are no timeout issues and data integrity is higher. This is better for machine-to-machine programming than Terminal Mode. In this case, the command string consists of an ASCII <Esc> (Escape) character (hex 1B), followed by the desired alphanumeric command, and then completed by a carriage return <cr> (Enter). Escape commands are not echoed back as they are entered. This means that characters that are typed will not be displayed in the software terminal window.

An example of entering an Escape command string to request only the last data record would be entered like this:

<Esc>4<cr>

The following table shows all the available Terminal Mode and Escape commands. Commands with the “\$” symbol in the descriptions below require that the instrument password be sent before the command can be sent.

Table 8-2 Escape Commands

Command	Description
1	Request settings report
2	Request All data report
3	Request New data report
4	Request Last data report
7	Request alarm event report
A	Network address command
C	Clear data log file - \$
D	Get/Set date part of the real time clock - \$
H	Help menu
T	Get/Set time part of the real time clock - \$
Z	Enable remote control - \$
AR	Get/Set Analog output range - \$
CO	Get/Set analog concentration offset - \$
CR	Get/Set analog concentration range - \$
CA	Clear alarm log file - \$
CU	Get/Set concentration units - \$
DS	Report data log channel descriptors
DT	Get/Set the date and time of the real time clock - \$
HS	Get/Set Ethernet flow control - \$
ID	Get/Set location ID or address - \$

Table 8-2 Escape Commands (Continued)

Command	Description
OP	Get/Set operation state - \$
PR	Print report - 0-Settings, 1-Data, 2-Alarm
PW	Unlock protected and User commands (User setting) - \$
QH	Report Data Record Header
RQ	Report current readings without header
RV	Report Model/Part/Revision
SB	Get/Set baud rate - \$
SS	Get Met One serial number
ST	Get/Set sample time (data log period) - \$
TS	Get/Set timestamp mode - \$
ROP	Get/Set Operation state report - \$
SPW	Get/Set user password - \$
BKGD	Get/Set background offset - \$
FTSP	Get/Set filter temperature set point - \$
SPAN	Get/Set span audit - \$
RTPER	Get/Set real-time average period - \$
TPRES	Get/Set tape advance pressure - \$

The following table shows the commands associated with editable settings, along with the default value for the setting and the settable range.

Table 8-3 Command Ranges

Description	Range	Default	Command
Location	1 - 999	1	ID
Data average period (Minutes)	0-1 MIN,1-5 MIN, 2-10 MIN,3-15 MIN, 4-30 MIN,5-1 HR	5-1 HR	ST
Real-time concentration period (Minutes)	5 - 60	30	RTPER
Serial port baud rate (BPS)	2-1200,3-2400, 4-4800,5-9600, 6-19200,7-38400, 8-57600,9-115200	5-9600	SB
Ethernet Flow Control	0-NONE,1-RTS/CTS	0-NONE	HS
Ethernet Timeout (Seconds)	0 - 3600	0-OFF	NETTO
Set User password (0 is no password)	0 - 9999	0	SPW

Table 8-3 Command Ranges (Continued)

Description	Range	Default	Command
Analog output concentration range ($\mu\text{g}/\text{m}^3$)	0-100 $\mu\text{g}/\text{m}^3$, 1-200 $\mu\text{g}/\text{m}^3$, 2-500 $\mu\text{g}/\text{m}^3$, 3-1000 $\mu\text{g}/\text{m}^3$, 4-2000 $\mu\text{g}/\text{m}^3$, 5-5000 $\mu\text{g}/\text{m}^3$, 6-10000 $\mu\text{g}/\text{m}^3$	3- 1000 $\mu\text{g}/\text{m}^3$	CR
Analog output concentration offset ($\mu\text{g}/\text{m}^3$)	0--15 $\mu\text{g}/\text{m}^3$, 1--10 $\mu\text{g}/\text{m}^3$, 2--5 $\mu\text{g}/\text{m}^3$, 3-0 $\mu\text{g}/\text{m}^3$, 4-5 $\mu\text{g}/\text{m}^3$	3-0 $\mu\text{g}/\text{m}^3$	CO
Concentration units	0- $\mu\text{g}/\text{m}^3$, 1- mg/m^3	0- $\mu\text{g}/\text{m}^3$	CU
DAC analog output range	V, 1-0-2.5 V, 2-0-5.0 V	2-0-5.0 V	AR
Hourly concentration data timestamp is either ENDING or BEGINNING hour only when Data Average Period is 1-HR.	0-ENDING, 1-BEGINNING	0- ENDING	TS
Concentration calibration offset ($\mu\text{g}/\text{m}^3$)	-0.05 - 0.05	0.0	BKGD
Span audit verification	0.4 - 1.0	0.780	SPAN
Tape advance pressure (mmHg)	50 - 350	100.0	TPRES

8.4 Using Met One Comet Communications Software

Comet is a communications terminal program which can retrieve data from the BAM 1022 PLUS using either a direct local connection or a remote connection via various modem types or even an IP address.

The Comet program is very simple and easy to use without having to navigate any of the BAM 1022 PLUS terminal menus.




Figure 8-4 Comet Program Interface

Warning: A Silicon Labs CP210x Driver for the USB connection must be installed before connecting to the USB Type B port.

Driver download weblink: <https://www.silabs.com/products/development-tools/software/usb-to-uart-bridge-vcp-drivers>

NOTE: Before using the USB Type B port, ensure an existing RS-232 connection is disconnected.

The Comet program is available from the Met One Instruments website: <https://metone.com/products/comet/>

Install the program on the computer, then run it from the Programs directory. Create a new station for the BAM 1022 PLUS and then use it to retrieve the data from the BAM 1022 PLUS monitor.

The Comet program has a “Terminal” button which provides access to the BAM just as when using any other terminal program.

8.5 Data Format & Example Reports

Samples of the more common reports and file downloads are shown in the following sections.

8.5.1 Settings Report

Issue the 1-command to output the Settings report.

```
BAM 1022 PLUS Settings Report
2019-08-19 07:33:07

  Station ID, 1
  Serial Number, X25504
    Firmware, 82912, R2.1.0
    Display, 82451, R1.1
    Digital 1, BX-597A, 10893, R1.0.1

  MET Average, 1 HR
  Time Stamp, ENDING
  Conc Units, µg/m3
  Standard Temp, 25 C

  Tape Period, 1 HR
  Tape Pressure, 100
  RealTime Period, 15
    K, 1.000
  Background, 0.0000
  Usw, 0.269
  Span Membrane, 0.780
  Factory Mode, OFF

  FT Set Point, 45.0
  FT P-Gain, 0.500
  FT I-Gain, 0.300

  RS-232, 38400
  Flow Control-232, NONE
  RS-485, 115200
  Modbus Port, RS-232
  Modbus Address, 1
  Byte Order, 512

  IP Config, Static, DHCP
  IP Address, 0.0.0.0, 0.0.0.0:7500
  Subnet Mask, 0.0.0.0, 0.0.0.0
  Gateway, 0.0.0.0, 0.0.0.0

  Name, Offset, Slope
  Flow, -0.413, 1.040
  AT, 0.000
  BP, 0.000
  FT, -0.283
  UPPER, 0.000
  LOWER, 0.000
  FRH, 0.000

  Conc Range, 1000 µg/m3
  Conc Offset, 0 µg/m3
  Analog Range 1, 0-2.5 V
  Analog Range 2, 0-2.5 V
    DAC Cal 1, 0.0,-1,2.5,29745
    DAC Cal 2, 0.0,-6,2.5,29723

  RealTime Alpha, 0.2316
  RealTime Gamma, 0.1500

  Sound Volume, 10
  Language, English
```

8.5.2 User Data Log Report

Issue the 2, 3, or 4-command to output the User Data Log report.

Data Report
2019-07-18 09:41:18
Station, 1, X25505

Time,ConcRT($\mu\text{g}/\text{m}^3$),ConcHR($\mu\text{g}/\text{m}^3$),ConcS($\mu\text{g}/\text{m}^3$),Flow(lpm),WS(m/s),WD(Deg),AT(C),RH(%),BP(mmHg),FT(C),FRH(%),Status

The user data is stored at the MET Average period.
The CONCHR and ConcS values are not averaged over the MET Average period.
The number of fields is 13, the records size is 52 bytes.
The file size is 1,122 Kbytes. The number of data records is 22,095.
When the data file is full the oldest data event record is overwritten.
The table below shows the file duration for the MET Average period.

Table 8-4 User Data Storage Capacity

Period (min)	File Size (Days)	File Size (Months)	File Size (Years)
1	15.3	0.5	0.0
5	76.7	2.6	0.2
10	153.4	5.1	0.4
15	230.2	7.7	0.6
30	460.3	15.3	1.3
60	920.6	30.7	2.5

8.5.3 Alarm Log Report

Issue the 7-command to output the Alarm Log report.

Alarm Report

2014-05-14 17:02:30

Location, 123, I10220

Time,Alarm

2014-05-14 17:02:30,TAPE BREAK,14

2014-05-14 17:02:30,BETA DETECTOR,500

2014-05-14 17:02:30,SENSOR RANGE,FLOW,-6.0

2014-05-14 17:02:30,SENSOR RANGE,AT,-50.0

2014-05-14 17:02:30,SENSOR RANGE,RH,0.0

2014-05-14 17:02:30,SENSOR RANGE,BP,375.0

2014-05-14 17:02:30,SENSOR RANGE,UPPER,228.0

2014-05-14 17:02:30,SENSOR RANGE,LOWER,228.0

2014-05-14 17:02:30,SENSOR RANGE,FT,0.0

2014-05-14 17:02:30,SENSOR RANGE,FRH,0.0

2014-05-14 17:02:30,SENSOR RANGE,BOX,0.0

2014-05-14 17:02:30,SENSOR RANGE,BETA,500.0

2014-05-14 17:02:30,SENSOR RANGE,FLOW,21.0

2014-05-14 17:02:30,SENSOR RANGE,AT,70.0

2014-05-14 17:02:30,SENSOR RANGE,RH,98.0

2014-05-14 17:02:30,SENSOR RANGE,BP,825.0

2014-05-14 17:02:30,SENSOR RANGE,UPPER,818.0

2014-05-14 17:02:30,SENSOR RANGE,LOWER,818.0

2014-05-14 17:02:30,SENSOR RANGE,FT,60.0

2014-05-14 17:02:30,SENSOR RANGE,FRH,98.0

2014-05-14 17:02:30,SENSOR RANGE,BOX,98.0

2014-05-14 17:02:30,SENSOR RANGE,BETA,20000.0

2014-05-14 17:02:30,TAPE ADVANCE,250.0

2014-05-14 17:02:30,FLOW FAILURE,0.0

2014-05-14 17:02:30,NOZZLE FAILURE,UP

2014-05-14 17:02:30,NOZZLE FAILURE,DOWN

2014-05-14 17:02:30,NOZZLE FAILURE,FOIL INSERT

2014-05-14 17:02:30,DIGITAL LINK DOWN

2014-05-14 17:02:30,POWER OUTAGE

2014-05-14 17:02:30,MAINTENANCE

The Alarm file can store 200 events.

When the Alarm file is full the oldest alarm event record is overwritten.

9 THEORY of OPERATION

When beta rays emitted from the radioactive decay of ^{14}C (carbon-14) interact with nearby matter they lose their energy through inelastic collision, absorption, scattering, or other forms of attenuation. The process is known as beta-ray attenuation and is the principle of operation of the BAM 1022 PLUS. When matter is placed between the radioactive ^{14}C source and a device designed to detect beta rays, such as a photomultiplier tube with a scintillator, beta rays are absorbed and/or their energy diminished. This results in a reduction in the flux of beta rays detected. The magnitude of the reduction in detected beta rays is a function of the mass of the absorbing matter between the ^{14}C beta source and the detector.

The beta ray flux passing through absorbing matter, such as dust deposited on a filter tape, decreases nearly exponentially with the mass through which it passes according to Equation 1.

Equation 1

$$M = \frac{S}{\mu} \ln \left(\frac{I_0}{I} \right)$$

In Equation 1, I_0 is the measured beta ray intensity (counts per unit time), at the beginning of the measurement cycle, I is the measured beta ray intensity at the end of the measurement cycle. μ is the absorption cross section of the material absorbing the beta rays (cm^2/g), and S is spot size (cm^2). M is the change in mass that occurs between the source and the detector during the measurement cycle.

It is a *differential* measurement: what is being measured is the change in mass that occurs during the measurement cycle. For the BAM 1022 PLUS this change in mass is *mainly* caused by particulate deposition onto the filter tape during the sampling process and changes in air density above and below the filter tape during the measurement process caused by fluctuations in temperature and pressure. The BAM 1022 PLUS continuously monitors the air temperature and pressure above and below the filter tape, determines the changes in these measured parameters during the measurement cycle and then compensates for them in order to accurately determine mass deposition that occurs on the filter tape during the measurement event. The filter tape mass remains constant during the measurement process and therefore is not part of the differential mass.

What makes the beta attenuation method so successful and so versatile is that the absorption cross section " μ " is, to an excellent approximation, dependent only on mass (and not on chemical composition or optical properties) for species likely to be sampled during ambient monitoring.

To convert sampled mass $M(mg)$ into aerosol concentration (instrument output), the following scaling factor is used:

Equation 2

$$C \left(\frac{mg}{m^3} \right) = k \frac{M(mg)}{Q(m^3)} + BKGD \left(\frac{mg}{m^3} \right)$$

The “k” factor is determined experimentally *during the factory calibration process* by comparing the mass output of the BAM 1022 PLUS under test with the mass output of a transfer standard beta gauge that has been calibrated against gravimetrically traceable standards.

“Q” is the sampled volume during the measurement. “BKGD” is the recorded mass value of the BAM 1022 PLUS under test in the absence of any mass accumulation and is determined in the field.

10 PARTS and ACCESSORIES

The following parts are available from Met One for maintenance, replacement, service, and upgrades. If you are unsure about which part is required, please contact the Service department. Some of these parts require technical skills or special considerations before use or installation.

Table 10-1 Parts and Accessories

Consumables

Description	Part Number	Graphic
Filter Tape Roll, PTFE, 30mm x 50 m	460185	
Filter Tape Core Tube, Gray Plastic	8150	
Cotton-Tipped Applicators, nozzle cleaning, 100 pack Solon #362	995217	
Backup Battery, Lithium, Coin Cell (CR 1216)	390068	

Tools

Rubber Nozzle Seal Tool	7440	
Flow Inlet Adapter Kit (Leak Test Valve)	BX-305	
Zero Filter Calibration Kit, with valve Same as BX-305 but with 0.2 micron filter and Inlet Cover (81418)	BX-302	
Volumetric Flow Calibrator Flow, Temp, and Pressure Reference Standards Met One recommended flow audit meter	Swift 25.0	

Flow System Components

Description	Part Number	Graphic
Flow Sensor, Mass, 0-20 LPM, Internal Assembly	82982	
Flow Controller Assembly	82834	
Filter RH Sensor, Replacement Only	80212-1	
Filter Temperature Sensor, Replacement Only	9279-3	
Flow Sensor Debris Filter Element	580292	
O-Ring, Nozzle, 1 required	720066	
O-Ring, Inlet Tube Receiver, 2 required	720069	
Pump Box Enclosure Assembly, 110 VAC Medo	BX-141	
Replacement 110 VAC Medo Pump	82044	
Rebuild Kit for 110 VAC Medo Pump	680839	
Pump Box Enclosure Assembly, 220 VAC Gast	BX-142	
Pump Box Enclosure Assembly, 120 VAC Gast	BX-143	
Replacement 220 VAC Gast Pump Kit	83084	
Replacement 120 VAC Gast Pump Kit	83084-1	
Pump Service Kit for Gast Pump	680828	

Inlet Components

PM10 Inlet Head, EPA Specified	BX-802	
PM _{2.5} Very Sharp Cut Cyclone	BX-808	
O-Ring Kit, for BX-808 Cyclone, set of 8	720105	
O-Ring Kit, for BX-802 PM10 Head, set of 3	8965	
Inlet Heater, 110 VAC	80559	
Inlet Heater, 220 VAC	80559-1	
Insulation Sleeve for Inlet Heater	9123-2	

Meteorological Sensors

Combination Ambient Temperature and Barometric Pressure Sensor Standard Accessory	BX-597A	
Digital Signal Cable, BX-597A Sensor to BAM 1022 PLUS	82929	

Miscellaneous Accessories

Tape Spool Cover, Replacement, Sold Individually	9185	
Outdoor Enclosure, Replacement	BX-922	
Fan Filter with Fan Guard	590078	
Pump Box Fan (100-240VAC)	590086	

Standard Shipping Accessory Kit (PN: 83035)

Description	Part Number	Initial Qty.
AC Power Cable	400100	1
USB Cable, A-B Male, 4.9 Feet	500784	1
RS-232 Serial Communication Cable w/ Female DB9, 6 Feet	82629	1
Filter Tape	460185	1
Fuse, 8A, Slow-blow	590854	2
Grounding Cable	9528	1
Allen Wrench 5/64	99300	1
6" Applicator, Wooden, Cotton Tip, Pack of 10	995217	1
Mass Foil Set (includes zero and span tools)	80307	1
Rubber Nozzle Seal Tool	7440	1
Pipe Seal Assembly	8119	1
Software Placard	82984	1
Digital Signal Cable, BX-597A Sensor to BAM 1022 PLUS	82929	1

11 OPTIONAL BAM 1022 PLUS CONFIGURATIONS

The BAM 1022 PLUS can be supplied with a variety of optional accessories to meet specific monitoring needs. Contact the Met One Instruments sales team for details about any of the following options.

11.1 Comet Cloud Service Data Modem

The BAM 1022 PLUS is compatible with the Comet Cloud Service (CCS). The CCS Modem 2 is available for International customers (GSM connectivity). The CCS Modem-LTE is available for US customers. Averaged data is reported to a secure cloud site every 15 minutes domestically and 1 hour internationally. The modem location is automatically available from the internal GPS and the first year of data service is included with the CCS modem.

11.2 Wind Sensor Options

The BAM 1022 PLUS can be equipped with an optional combination wind speed and direction sensor. There are both analog and sonic type sensors available.

11.2.1 BX2-034

The BX2-034 sensor provides traditional analog cup and vane wind measurements. It connects to the BAM 1022 RS485 terminals on the rear of the monitor via the 10701 cable. These terminals provide power to the sensor and collect its digital output string to provide wind speed and direction information. This type of sensor requires manual orientation for proper alignment when deployed.

BX2-034 Wiring Connections

10701 WIRE COLOR	BAM 1022 TERMINAL NAME
BROWN/WHITE	SHIELD
BLACK (PWR GND)	GND
ORANGE	RS485 -
WHITE	RS485 +
RED	DC POWER
GREEN 9SIG GND)	GND

11.2.2 AIO 2

The AIO 2 sensor provides sonic wind measurements. It connects to the BAM 1022 PLUS through the RS485 terminals on the rear of the monitor. These terminals provide power to the sensor and collect its digital output string to provide wind speed and direction information.

This type of sensor includes an internal compass for wind direction correction and does not require manual orientation when deployed.

12 ACRONYMS and ABBREVIATIONS

Acronyms and Abbreviations

The following is a list of acronyms and abbreviations that may be used within this operating manual:

ASTM American Society for Testing and Materials
CFR Code of Federal Regulations
CV Coefficient of Variation
CTS Calibration Transfer Standard
EPA Environmental Protection Agency
FEM Federal Equivalent Method
FRM Federal Reference Method
HEPA High-Efficiency Particulate Air
I/O Inputs/Outputs
NAAQS National Ambient Air Quality Standards
NIST National Institute of Standards and Technology
PM Particulate Matter
PM₁₀ Particulate Matter $\leq 10 \mu\text{m}$
PM_{2.5} Particulate Matter $\leq 2.5 \mu\text{m}$
QA/QC Quality Assurance/Quality Control
QA Quality Assurance
QC Quality Control
Qa Actual Flow Rate
RH Relative Humidity
SCC Sharp Cut Cyclone
SOP Standard Operating Procedure
SRM Standard Reference Material
TEMP Temperature
TSP Total Suspended Particulate
VSCC Very Sharp Cut Cyclone